

E6300F 挖掘机

零部件图册

E6300F HYDRULIC EXCAVATOR PARTS CATALOG



山东临工工程机械有限公司

SHANDONG LINGONG CONSTRUCTION MACHINERY CO.,LTD.

配件与服务 Spare parts and services

对于山东临工机器的所有者来说，只有山东临工配件和服务才能够使您的机器更好地保持原有的特性。

For the owner of the machines of SDLG, only the spare parts and services of SDLG can make your machine to better maintain the original features.

只有山东临工才能够为您提供完美匹配且优质纯正的配件和对您的机器了如指掌的专业维修人员。这样才能保证及其可持续的高产能和更长的使用寿命。

Only SDLG is able to provide you with the perfect match of pure quality spare parts for your machine and knowledge of professional maintenance staff. Only in this way it can ensure sustainable high productivity and longer service life.



E6300F 挖掘机零部件图册

E6300F HYDRULIC EXCAVATOR PARTS CATALOG

BOM发布时间:2017-08-27 14:56:10 文档创建时间:2017-10-27 13:16:05

BOM RELEASE DATE:2017-08-27 14:56:10 FILE CREATION DATE:2017-10-27 13:16:05

山 东 临 工 工 程 机 械 有 限 公 司

SHANDONG LINGONG CONSTRUCTION MACHINERY CO., LTD.

地址：中国 临沂经济技术开发区临工工业园

Add : Lingong Industry Park, Economic & Technological Development Area, Linyi, Shandong 276023, P.R.China

电话：86-0539-8785668

Tel : 86-0539-8785624/86-0531-66590955

传真：86-0539-8785698

Fax : 86-0539-8785618/86-0531-66590959

技术服务：86-0539-8785800 400-6587999

Web : www.sdlg.cn www.lcm.cn

前言

E6300F挖掘机零部件图册，是为了方便用户使用、维修和保养而绘制的，以供在使用过程中查阅及参考，也可帮助用户了解本机的结构和装配关系。发动机的零部件详见其随机资料，图册不再绘出。

本图册按系统划分绘制出了各零部件的图形及其相互装配关系。凡装机后不可拆卸的部件（如焊接件、铆合件），只标出部件代号，不另列其组成零件。本图册明细表采用中英文对照编排。

本图册根据E6300F标准配置编绘，其它非标准配置，可参照执行，详情请咨询山东临工、或当地经销商、或登录山东临工网站查询。随着科技的进步，产品将会不断改进，故本图册的内容可能会有部分与以后的产品不一致，恕不另行通知。敬请用户在订购配件时，指明所购整车的出厂日期和编号。

编者
2017年10月

FOREWORD

This parts catalog of E6300F hydraulic excavator is made for the convenience of users to use, repair and maintain the machine, which can be referred in the process of using. It can also help the users to be familiar with the structure and assembly relation of the machine. Parts of the engine are showed in details in its structure handbook, which are no longer contained in the catalog.

The catalog identifies drawings and assembly relations of different parts according to the system. Components which can not be taken apart, such as welding parts or riveted assemblies, are marked only by their code without the list of their consisting parts. The list in the catalog is arranged in Chinese and English.

This catalog is based on the E6300F standard product, which can be a reference for the other nonstandard products, for more information, please consult SDLG, the local dealer or LinGong website. With the advancement of technology, we will keep on improving the product, so some content in the catalog may be inconsistent with the future products, which will not notice the users. When ordering the spare parts, please be kindly inform us the manufacturing date and serial number of the machine.

THE COMPILER
2017.10

目录 CONTENTS

A. 发动机系统 Diesel engine system

A0100-58-2100-014 发动机总成	
Engine assm t3/t2	20
A01401-11221536 发动机易损件包	
Repair kits for engine	22
A01402-11221536 发动机检修工具包	
Overhaul kit	24
A01403-11221536 汽缸盖套件	
Cylinder head kit	26
A01404-11221536 汽缸衬套套件	
Cylinder liner kit	28
A01405-11221536 发动机	
Engine	30
A01406-11221536 汽缸头	
Cylinder head	32
A01407-11221536 发动机缸体	
Cylinder block	36
A01408-11221536 曲轴箱通风套件	
Crankcase ventilation	38
A01409-11221536 气缸套和活塞	
Cylinder liner and piston	40
A01410-11221536 配气机构	
Valve mechanism	42
A01411-11221536 正时齿轮护罩	
Timing gear casing	44
A01412-11221536 泵驱动动力启动	
Pump drive power take-off	46
A01413-11221536 曲轴及附件	

Crankshaft and related parts	48
A01414-11221536 飞轮壳	
Flywheel housing	50
A01415-11221536 油底壳	
Oil sump	52
A01416-11221536 发动机支架	
Engine mounting	54
A01417-11221536 润滑系统	
Lubricating oil system	56
A01418-11221536 机油滤清器	
Oil filter	58
A01419-11221536 机油冷却器	
Oil cooler	60
A01420-11221536 燃油泵	
Fuel pump	62
A01421-11221536 燃油滤清器	
Fuel filter	64
A01422-11221536 油管组件	
Fuel lines:fuel filter -engine	66
A01423-11221536 喷油器和输油管	
Fuel lines,injectors	68
A01424-11221536 进气歧管和排气歧管	
Inlet manifold and exhaust manifold	70
A01425-11221536 涡轮增压器及附件	
Turbocharger with fitting parts	72
A01426-11221536 水泵和恒温器总成	
Water pump and thermostat housing	74
A01427-11221536 发动机电气系统	
Cable harness,engine	76
A01428-11221536 发电机及其附件	

Alternator with assembling details	80
A01430-11221536 起动机组件	
Starter element kit	82
A01431-11221536 预热器	
Pre-heater	84
A01432-11221536 发动机控制单元	
Ecu	86
A0120-58-4313-007 联轴器	
Pump with coupling	88
A0130-58-2560-002.20580 进气系统	
Air inlet system	90
A0131-58-2560-016 预滤器	
Precleaner	92
A0140-58-2180-005 发动机安装	
Engine mounting	94
A0140-58-2520-002 排气系统	
Exhaust	96
A0200-58-2340-026 燃油箱	
Fuel tank	98
A0200-58-2350-005 燃油管路总成	
Fuel supply system	100
A0203-58-2350-012 油水分离器	
Water separator	104
A0203-58-2350-001 油水分离器	
Fuel filter w/o heater	106
A0220-58-2344-006 燃油加油泵及附件	
Fuel filling pump	108
A0300-58-2610-003 散热器管路	
Radiator connections	110
A0301-58-2610-005 散热器	

Radiator	114
A0302-58-2581-002 中冷系统	
Charge air cooler	116
A0303-58-2630-002 风扇	
Fan and acc	118

E. 行走系统 Travel system

E0920-58-7753-171 履带链条	
Track chain	122
E0920-58-7757-023 履带导件	
Track guard	124
E0930-58-7751-011 导向轮总成	
Front idler	126
E0940-58-7756-025 支重轮总成	
Track guard	128
E0950-58-7758-014 涨紧装置总成	
Track tensioner	130
E0960-58-7755-009 托链轮	
Sprocket	132
E0970-58-7752-007 驱动轮	
Drive wheel	134
E0980-58-7150-005 行走马达盖板	
Cover plate	136

F. 液压系统 Hydraulic system

F1010-58-9111-069 液压油箱总成	
Hydraulic tank	140
F1100-58-9112-036 工作泵系统	
Hydraulic pump system	142
F1100-58-9130-004 液压泵	

Hydraulic pump	144
F1201-58-9114-002 滤清器	
Filter	146
F1201-58-9140-069 伺服系统	
Servo system	148
F1202-58-9140-055 主阀到电磁阀管路总成	
Control valve to solenoid valve	150
F1203-58-9112-048 伺服系统	
Servo system	154
F1220-58-9112-039 液压操纵总成	
Hydraulic lines	156
F1220-58-9112-040 液压操纵总成	
Hydraulic lines	158
F1220-58-9120-016 主阀装配总成	
Main valve assembly	160
F1222-11214526-01 主阀	
Control valve	162
F1222-11214526-02 主阀	
Control valve	166
F1222-11214526-03 主阀	
Control valve	172
F1222-11214526-04 主阀	
Control valve	176
F1221-58-9140-058 伺服系统，控制阀到遥控阀	
Servo system,control valve to remote control valve	180
F1222-58-9140-056 伺服系统，泵管线和过滤器安装件	
Servo system,pump piping	182
F1223-58-9140-057 伺服系统，控制阀管线	
Servo system,control valve piping	186
F1230-58-9140-123 伺服系统	

Servo system	190
F1260-14400042 先导控制阀	
Control lever	192
F1270-14400043 先导控制阀	
Control lever	196
F1300-58-9160-054.20997 液压装置	
Extra hyd equipment	200
F1300-58-9160-060.20997 工作液压,动臂油管	
Working hydraulic system	202
F1300-58-9160-062.20997 液压装置	
Extra hyd equipment	204
F1301-58-9140-040 伺服系统	
Servo system	206
F1314-58-9743-018 动臂油缸总成	
Boom cylinder	208
F1324-58-9753-003 斗杆油缸总成	
Arm cylinder	210
F1334-58-9755-002 铲斗油缸总成	
Bucket cylinder	212
F1410-58-9112-038.20581 回转液压总成	
Swing hydraulic system	214
F1420-58-4312-003 回转马达减速机总成	
Drive unit	216
F1422-11214026 回转减速机	
Swing gearbox	218
F1421-14402196 回转马达总成	
Swing motor	222
F1420-58-4430-001 回转接头总成	
Turning joint	226
F1500-58-9112-042 行走液压系统	

Travel hydraulic system	228
F1500-58-9140-047 行走先导阀总成	
Travel control valve assembly	230
F1510-58-9140-054 主阀至行走先导阀管路总成	
Servo system	232
F1511-58-4311-005.21892 行走马达及减速机总成	
Drive unit	234
F1515-14408561 行走减速机	
Travel gearbox	236
F1514-14408649 行走马达	
Travel motor	240
F1600-58-9112-037 油散总成	
Oil radiator assembly	246

H. 工作装置 Working equipment

H1700-58-9751-052 工作装置附件	
Pin install, arm 2.55m hd	250
H1710-58-9251-173 工作装置,销连接	
Pin-bucket	252
H1720-58-9752-058 工作装置连杆总成	
Structure_linkage	254
H1730-58-9741-048 大臂与润滑脂配管	
Boom and grease piping	256
H1730-58-9741-049 工作装置,销连接	
Pin install-boom rear	258
H1730-58-9741-050 工作装置,销连接	
Pin install-boom rear	260
H1730-58-9751-054 工作装置附件	
Structure, 2.55m arm hd	262
H1800-2618000650 铲斗总成	

Bucket assembly	264
-----------------	-----

K. 车架 Frame

K2400-58-7185-008.20581 上架总成	
Superstructure frame assembly	268
K2400-58-8314-012 密封	
Sealing	270
K2500-58-4920-003.20581 回转机构总成	
Swing gear system	272
K2600-58-7181-004 下架	
Lower frame	274
K2601-2626001233 X架护板	
Protecting plate	276
K2800-58-7160-160 配重	
Counter weight	278

L. 驾驶室系统 Cab group

L2900-58-8100-001 驾驶室	
Cab system	282
L2901-14406705 驾驶室	
Cab	284
L2902-14406705 驾驶室	
Cab	286
L2903-14406705 驾驶室	
Cab	288
L2904-14406705 驾驶室	
Cab	290
L2905-14406705 驾驶室	
Cab	294
L2921-14404917 推拉窗	

Slide window	296
L2922-14404914 驾驶室门	
Door	300
L2940-58-8416-006 后视镜	
Rear view mirror	304
L2950-58-8600-001 内部遮阳板	
Sun visor	306
L2950-58-8600-003 遮阳板	
Sun visor	308
L2960-58-8810-001 仪表盘	
Instruction panel assembly	310
L3000-58-8520-002 座椅	
Driver seat	312
L3013-14402622 带安装零件的驾驶座	
Operator seat with fitting parts	314
L3100-58-8110-001 驾驶室地板	
Cab floor	316
L3100-58-8110-002 驾驶室地板	
Cab floor	318
L3100-58-8314-001 海绵组件	
Sealing	320
L3110-58-8700-001 空调单元	
Air conditioning system	322
L3200-58-8810-002 仪表盘控制板	
Instruction panel assembly	324
L3500-11220328 空调冷却和加热器	
Air conditioning system	328
L3600-58-8970-002.21986 标志与标识	
Sign and logo	332

M. 覆盖件系统 Cover system

M3300-58-8222-007.20581 机罩总成	
Engine bonnet assembly	336
M3300-58-8226-100.20580 发动机机罩	
Engine bonnet system	340
M3330-58-8226-008 左罩总成	
Hood	344
M3350-58-8222-014 上盖板总成	
Cover	346
M3400-58-8226-119 机罩工具箱	
Hoods and covers	348
M3400-58-8270-045 扶栏	
Hand rail	352
M3400-58-8416-002 后视镜	
Rear view mirror	354
M3400-58-8910-046 防滑垫	
Slip protection	356
M3430-58-8222-102.20581 盖板总成	
Cover	358
M3430-58-8370-059 盖板总成	
Cover	360
M3430-58-8600-007 盖板总成	
Cover	362
M3600-58-8970-006 铭牌	
Decal_sdlg_plant	364
M3600-58-8970-024.20581 标志与标识	
Decal	366
M3600-58-8970-030 标志与标识	
Sign and logo	368

M3600-58-8970-031 标志与标识	
Sign and logo	370
M3600-58-8970-025 标识标志	
Decal	372

N. 空调系统 Air conditioner system

N3510-58-8700-004.20581 空调系统	
Air conditioning system	376
N3511-14403219 冷凝器	
Condenser	380

P. 电气系统 Electric system

P4300-14405199 驾驶室电气	
Cab electric system	384
P3700-58-3100-002 电池与安装系统	
Battery and mounting	388
P3700-58-3714-002 电源电气系统	
Electrical assembly-power	390
P3710-58-2142-001 电源外接插头	
Cable joint	392
P4100-58-3300-001 钥匙	
Cotter	394
P4100-58-3500-004 动臂线束	
Boom cable(e6300)	396
P4100-58-3500-014 工作灯	
Work lamp	398
P4100-58-3621-001 喇叭	
Horn	400
P4100-58-3710-009.20581 主线束总成	
Main cable harness	402

P4100-58-3860-002 电子传感器	
Sensor	404
P4101-58-3690-001 开关	
Switch	406
P4102-58-3670-003 电子装置	
Electronic unit	408
P4103-58-3640-007 开关	
Switch	410
P4110-58-3670-004 基本控制单元	
Basic control	412
P4300-58-3634-001 洗涤器	
Water jet unit	414
P4300-58-3640-005 内部电子系统	
Control unit	416
P4300-58-3660-001 V-ECU	
V-ecu install	418
P4300-58-3660-009 远程信息处理	
Telematics control unit	420
P4300-58-3670-008.21974 键区	
Keyboard	422
P4300-58-3710-017 仪表盘电缆线束	
Cable harness	424
P4300-58-3723-003.20401 保险丝和继电器中央接线盒	
Fuse and relay unit	426
P4300-14408224 保险丝和继电器中央接线盒	
Fuse and relay unit	428
P4300-58-3810-002 显示器	
Display panel	430
P4300-58-3932-002 收音机	
Radio cassette	432

P4400-58-3710-008 发动机线束总成	
Engine cable install	434
P4400-58-3723-012 预热器总成	
Preheater relay	438
P4400-58-8730-001 控制单元装置	
Control unit	440


A 发动机系统

DIESEL ENGINE SYSTEM



山东临工工程机械有限公司
SHANDONG LINGONG CONSTRUCTION MACHINERY CO.,LTD.

发动机总成 Engine assm t3/t2




A0100-58-2100-014

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221536	发动机	Engine	Y	1
2	14406900	机油管	Oil hose	Y	1
3	14400358	机油管	Oil hose	Y	1
4	11211055	曲轴箱透气管	Hose	Y	1
5	11210325	管夹	Clip	Y	1
6	11210259	管夹	Clip	Y	1
7	11210027	喉箍	Hose clamp	Y	1
8	11214763	法兰螺钉	Screw	Y	6
9	11214773	六角螺钉	Screw	Y	1
10	11210036	法兰螺钉	Flange screw	Y	2
11	11210034	法兰螺钉	Flange screw	Y	4
12	11222289	护套	Cover	Y	1
13	14400351	支架	Bracket	Y	1


SDLG

发动机易损件包 Repair kits for engine




A01401-11221536

发动机检修工具包 Overhaul kit



A01402-11221536


汽缸盖套件 Cylinder head kit



A01403-11221536


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221176	螺栓	Y	26	
2	11221982	密封垫	Y	3	
3	11221185	密封垫	Y	1	
4	11221333	压力管	Y	3	
5	11221327	O型圈	Y	6	
6	11221240	丝堵	N	1	
7	11215680	密封垫	Y	1	
8	11221253	平垫片	Y	4	
9	11220877	垫片	Y	1	
10	11221363	密封环	Y	2	
11	11221359	六角螺母	Y	4	
12	11220555	密封圈	Y	1	
13	11221344	六角螺母	Y	12	
14	11220541	垫片	Y	3	
15	11221358	密封垫	Y	1	
16	11220542	垫片	Y	1	
17	11221328	密封环	Y	6	
18	11221334	压力管	Y	3	
19	11221371	O型圈	Y	1	
20	11221343	隔离套管	Y	12	
21	11221341	密封垫	Y	6	
22	11221177	汽缸头衬垫	Y	1	
23	11221179	汽缸头衬垫	Y	1	
24	11221178	汽缸头衬垫	Y	1	
25	11221357	双头螺柱	Y	4	
26	11221347	密封垫	Y	1	
27	11221870	密封环	N	2	
28	11221335	压力管	Y	2	

汽缸衬套套件 Cylinder liner kit




A01404-11221536

发动机 Engine



A01405-11221536


汽缸头 Cylinder head



A01406-11221536


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221161	汽缸头	Y	1	
2	11221162	丝堵	Y	5	
3	11221163	塞芯	N	5	
4	11221164	塞芯	N	2	
5	11221165	阀导轨	Y	12	
6	11221166	O型圈	Y	12	
7	4110002126009	阀弹簧	Y	12	
8	11221168	固位器	Y	12	
9	11221169	阀套筒	Y	24	
10	11221170	止推垫圈	N	12	
11	11221171	圈	N	12	
12	11221172	阀座	Y	6	
13	11221979	入口阀	Y	6	
14	11221174	阀座	Y	6	
15	11221175	排气阀	Y	6	
16	11221176	螺栓	Y	26	
17	11221177	汽缸头衬垫	Y	1	
18	11221178	汽缸头衬垫	Y	1	
19	11221179	汽缸头衬垫	Y	1	
20	11221180	导引销	Y	2	
21	11221181	线圈阀	N	1	
22	11221182	六角螺母	Y	1	
23	11220881	螺塞	Y	6	
24	11221183	阀门室盖	Y	1	
25	11221184	帽	Y	1	
26	11221185	密封垫	Y	1	
27	11221186	密封垫	N	1	
28	11221187	油分离器	N	1	
29	11221188	螺栓	N	6	
30	11221189	密封件	Y	1	

汽缸头 Cylinder head



A01406-11221536


发动机缸体 Cylinder block



A01407-11221536

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221193	曲轴箱	Y	1	
2	11221194	轴衬	Y	14	
3	11221195	螺栓	Y	14	
4	11221196	塞	Y	1	
5	11221197	塞	N	2	
6	11221198	丝堵	N	2	
7	11216553	密封垫	Y	3	
8	11221199	塞	Y	1	
9	11221200	塞	N	1	
10	11221201	塞芯	N	10	
11	11221202	轴承轴衬	Y	1	
12	11221203	轴承轴衬	Y	6	
13	11221204	密封垫	N	1	
14	11221205	盖	N	1	
15	11221206	螺栓	N	2	
16	11221207	密封垫	Y	1	
17	11221208	法兰	Y	1	
18	4110002409112	螺丝	Y	2	
19	11219976	平垫片	Y	1	
20	11219977	螺栓	Y	1	
21	11221209	衬套	Y	1	
22	11219978	堵头	Y	1	
23	11215680	密封垫	Y	2	
24	11221210	塞	N	2	

曲轴箱通风套件 Crankcase ventilation




A01408-11221536

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221211	油分离器	N	1	
2	11221212	密封垫	N	1	
3	11221213	螺栓	N	2	
4	11221214	油线	Y	1	
5	11221215	软管夹	N	1	
6	11220879	排水阀	Y	1	
7	11221216	密封环	N	1	
8	11221985	回油管	Y	1	
9	11221218	夹	N	1	
10	11221219	连接夹	N	1	
11	11221220	螺栓	N	1	
12	11221221	软管夹	N	1	


SDLG

气缸套和活塞 Cylinder liner and piston



A01409-11221536


配气机构 Valve mechanism



A01410-11221536


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221226	支架	Y	1	
2	11221227	支架	Y	1	
3	11221228	支架	Y	5	
4	11221229	销	N	7	
5	11221230	摇臂	N	6	
6	11221231	摇臂轴	N	6	
7	11221232	定位环	N	12	
8	11221233	调节螺钉	N	6	
9	11221234	调节螺钉	N	6	
10	11221235	螺母	N	12	
11	11221236	推杆	Y	12	
12	11221237	挺柱	Y	12	
13	11221978	致动器	Y	1	
14	11221975	致动器	Y	1	
15	11221240	丝堵	N	1	
16	11221241	螺栓	N	7	
17	11221977	螺栓	Y	74	
18	11221243	螺栓	Y	3	
19	11221181	线圈阀	N	1	
20	11221983	凸轮轴	Y	1	

正时齿轮护罩 Timing gear casing



A01411-11221536

泵驱动动力启动 Pump drive power take-off




A01412-11221536

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221253	平垫片	Plane gasket	Y	1	
2	11221198	丝堵	Plug	N	1	
3	11221254	密封环	Sealing ring	Y	1	
4	11221255	盖板	Cover	Y	1	
5	4110002409063	法兰螺丝	Flange screw	Y	2	
6	11219978	堵头	Core plug	Y	1	
7	11221210	塞	Plug	N	1	
8	11215680	密封垫	Gasket	Y	1	

SDLG


曲轴及附件 Crankshaft and related parts



A01413-11221536

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221256	曲轴	Y	1	
2	11221257	主轴承	Y	7	
3	11221258	主轴承	Y	7	
4	11221259	主轴承	Y	7	
5	11221980	轴向推力垫片	Y	1	
6	11221261	座圈垫片	Y	1	
7	11221262	大端轴承	Y	6	
8	11221263	大端轴承	Y	6	
9	11221264	大端轴承	Y	6	
10	11221265	连接棒	Y	6	
11	11221266	轴衬	Y	6	
12	11221267	销	Y	12	
13	11221268	螺栓	Y	12	
14	11221269	减震器	Y	1	
15	11221270	锁垫圈	Y	1	
16	11221271	销	Y	1	
17	11221272	六角螺丝	N	5	
18	11221273	弹簧销	Y	1	
19	11221274	螺栓	Y	4	
20	11221275	带轮	Y	1	
21	4110002409139	螺栓	Y	4	
22	11221276	飞轮	Y	1	
23	4110002409085	起动齿轮环	Y	1	
24	11219992	丝堵	Y	5	
25	11219991	螺栓	Y	10	

飞轮壳 Flywheel housing




A01414-11221536

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221984	飞轮壳	Flywheel housing	Y	1	
2	11221278	衬套	Bushing	Y	2	
3	4110002409101	螺丝	Screw	Y	1	
4	11221279	螺栓	Screw	Y	2	
5	11221280	螺栓	Screw	Y	1	
6	11221987	螺栓	Screw	Y	2	
7	11219995	盖板	Cover plate	Y	1	
8	4110002409225	六角螺钉	Hexagon screw	Y	4	
9	4110002409097	罩	Cover	Y	1	
10	11221220	螺栓	Screw	N	3	
11	11220920	衬套	Bushing	Y	2	


SDLG

油底壳 Oil sump




A01415-11221536

发动机支架 Engine mounting



A01416-11221536


润滑系统 Lubricating oil system



A01417-11221536

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221290	油泵箱	Y	1	
2	11221291	密封圈	Y	1	
3	11220017	螺栓	Y	8	
4	11221292	密封垫	Y	1	
5	4110002409147	螺丝	Y	14	
6	11221293	弹簧销	Y	1	
7	11221294	吸管	Y	1	
8	11221295	螺栓	Y	2	
9	11221296	密封垫	Y	1	
10	11221206	螺栓	N	2	
11	11221297	传送阀	Y	1	
12	11221298	套筒	Y	1	
13	11221299	压缩弹簧	Y	1	
14	11221300	阀	N	1	
15	11221301	环	Y	1	
16	11221302	活塞	Y	6	

机油滤清器 Oil filter




A01418-11221536

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11220020	密封圈	Y	1	
2	11221303	密封圈	Y	1	
3	11220021	适配器	Y	1	
4	11220022	密封圈	Y	1	
5	11220735	螺栓	Y	1	
6	4110002409154	过滤器	Y	1	
7	4110002409151	填料	Y	2	
8	14400779	机油滤清器	Y	1	
9	4110002409152	插座	Y	1	
10	4110002409153	填料	Y	2	
11	4110002409150	插座	Y	2	


SDLG

机油冷却器 Oil cooler




A01419-11221536

燃油泵 Fuel pump




A01420-11221536

燃油滤清器 Fuel filter




A01421-11221536

油管组件 Fuel lines:fuel filter -engine



A01422-11221536


喷油器和输油管 Fuel lines, injectors



A01423-11221536


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	4110002126198	高压泵	Y	2	
2	4110002409199	O 型圈	Y	2	
3	11221323	推杆	Y	2	
4	11221324	螺栓	Y	4	
5	11221325	燃油调节器	Y	1	
6	11221241	螺栓	N	1	
7	11221241	螺栓	N	1	
8	11221326	喷射器	Y	6	
9	11221327	O型圈	Y	6	
10	11221328	密封环	Y	6	
11	11221329	爪	Y	6	
12	11221330	螺栓	Y	6	
13	11221331	高压轨道	Y	1	
14	11221891	压力传感器	N	1	
15	11221332	阀	N	1	
16	11221213	螺栓	N	3	
17	11221333	压力管	Y	3	
18	11221334	压力管	Y	3	
19	11221335	压力管	Y	2	
20	11221336	燃油管	Y	1	
21	4110002409188	密封环	Y	2	
22	4110002409187	空心螺丝	Y	1	
23	11221337	密封环	Y	4	
24	11221338	空心螺栓	Y	2	
25	11221339	O型圈	Y	1	
26	11220098	维修包	Y	1	

进气歧管和排气歧管 Inlet manifold and exhaust manifold



A01424-11221536


涡轮增压器附件 Turbocharger with fitting parts



A01425-11221536


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221354	涡轮增压器	Y	1	
2	11220826	橡胶软管	Y	1	
3	11221218	夹	N	2	
4	11221355	控制压力管	N	1	
5	4110002409334	密封环	Y	2	
6	4110002409335	空心螺丝	Y	1	
7	11220072	六角螺母	Y	1	
8	11220922	螺栓	Y	1	
9	11221357	双头螺柱	Y	4	
10	11221358	密封垫	Y	1	
11	11221359	六角螺母	Y	4	
12	11221360	双头螺柱	Y	4	
13	11220542	垫片	Y	1	
14	11221359	六角螺母	Y	4	
15	11221361	油线	Y	1	
16	11221253	平垫片	Y	4	
17	11216924	空心螺栓	Y	2	
18	11221362	回油管	Y	1	
19	11221363	密封环	Y	1	
20	11220877	垫片	Y	1	
21	4110002409112	螺丝	Y	2	
22	4110002409329	固位器	Y	1	
23	11221206	螺栓	N	1	
24	4110002409330	夹	Y	1	
25	11221213	螺栓	N	1	
26	11221364	轴衬	Y	1	
27	11221365	管夹	Y	1	

水泵和恒温器总成 Water pump and thermostat housing



序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221976	风扇托架	Y	1	
2	11221367	冷却泵	Y	1	
3	11221368	密封环	Y	1	
4	4110002409112	螺丝	Y	4	
5	11215689	塞子	Y	1	
6	11215680	密封垫	Y	1	
7	11221338	空心螺栓	Y	1	
8	11221369	接头	Y	1	
9	11221370	密封环	Y	2	
10	11221371	O型圈	Y	1	
11	11221241	螺栓	N	7	
12	11221372	节温器	Y	1	
13	11221373	密封环	Y	1	
14	11221374	弯管	N	1	
15	11221295	螺栓	Y	2	
16	11221375	V形带滑轮	Y	1	
17	11221206	螺栓	N	3	
18	11221376	丝堵	Y	1	
19	11215875	平垫圈	Y	1	
20	11221377	导向垫	Y	1	


发动机电气系统 Cable harness,engine



A01427-11221536


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221378	导线系统	Y	1	
2	11221379	支架	Y	1	
3	11214781	箍带	Y	7	
4	11221380	垫圈	N	1	
5	11221381	螺栓	Y	3	
6	11221382	支架	N	1	
7	11221383	支架	Y	1	
8	11221243	螺栓	Y	2	
9	11220958	板	Y	1	
10	11221295	螺栓	Y	4	
11	4110002409117	固定座	Y	1	
12	11215788	扎带	Y	1	
13	11221192	适配器	N	1	
14	11214762	密封垫	Y	1	
15	11216909	机油温度传感器	Y	1	
16	11221206	螺栓	N	3	
17	11221384	压力传感器	Y	1	
18	11221381	螺栓	Y	1	
19	11222263	传感器	Y	1	
20	11221386	螺栓	Y	2	
21	11221317	压力传感器	Y	1	
22	11221387	转速计	Y	1	
23	11221388	支架	Y	1	
24	11221389	双头螺柱	Y	2	
25	11221390	支架	Y	2	
26	11215788	扎带	Y	4	
27	4110002409118	夹	Y	2	
28	11221981	水位传感器	Y	1	
29	11220001	垫片	Y	1	
30	11221391	帽	Y	2	

发动机电气系统 Cable harness,engine



A01427-11221536

发电机及其附件 Alternator with assembling details




A01428-11221536

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221886	交流发电机	N	1	
2	11220960	电压稳压器	Y	1	
3	11220957	法兰螺母	Y	1	
4	4110002126324	带轮	Y	1	
5	4110002126326	支架	Y	1	
6	4110002126329	螺栓	Y	1	
7	4110002126328	垫片	Y	2	
8	4110002126327	螺母	Y	1	
9	11221887	垫圈	N	1	
10	11220014	螺栓	Y	1	
11	11221888	板	N	1	
12	4110002126330	螺栓	Y	4	
13	11221889	V型棱纹带	Y	1	


SDLG

起动机组件 Starter element kit




A01430-11221536

预热器 Pre-heater




序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	4110002126260	管接头	Nipple	Y	1
2	4110002126261	垫片	Gasket	N	3
3	4110002126262	加热器	Pre-heater	Y	1
4	4110002126263	弯管	Elbow pipe	Y	1
5	4110002126264	法兰螺栓	Screw	Y	4
6	4110002409340	螺丝	Screw	Y	2
7	4110002126058	螺栓	Screw	Y	2
8	4110002126267	隔板	Insulator	Y	3
9	4110002126242	接头	Nipple	Y	1
10	4110002126269	密封圈	Sealing ring	Y	1
11	11220870	六角螺钉	Screw	Y	1
12	4110002126271	绝缘材料	Insulator	Y	3
13	4110002126272	螺栓	Screw	Y	3
14	4110002126273	绝缘材料	Insulator	Y	2
15	4110002126142	螺栓	Screw	Y	2
16	11221890	软管	Hose	N	1

发动机控制单元 Ecu




A01432-11221536

联轴器 Pump with coupling



A0120-58-4313-007


进气系统 Air inlet system



A0130-58-2560-002.20580


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14401141	空气滤清器总成	Y	1	
2	14400366	进气胶管	Y	1	
3	11219788	进气连接钢管	Y	1	
4	11210293	接头	Y	1	
5	14407375	压力开关	Y	1	
6	11212354	进气管	Y	1	
7	11220571	管	Y	1	
8	11220570	管	Y	1	
9	11214257	管夹	Y	1	
10	11211650	管夹	Y	4	
11	11210054	气管	Y	1	
12	11212365	管夹	Y	2	
13	11211649	管夹	Y	1	
14	11210034	法兰螺钉	Y	4	
15	11214756	法兰螺钉	Y	2	
16	11210032	法兰螺钉	Y	4	
17	14405877	空气滤清器主滤芯	Y	1	
18	14405878	安全滤芯	Y	1	

预滤器 Precleaner



A0131-58-2560-016

发动机安装 Engine mounting




A0140-58-2180-005

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11212359	支架	Bracket	Y	1	
2	11212326	支架	Bracket	Y	2	
3	11212328	板	Plate	Y	1	
4	11212327	支架	Bracket	Y	2	
5	11212300	减振器	Rubber cushion	Y	2	
6	11212301	减振器	Bushing	Y	2	
7	11210435	挡板螺母	Nut	Y	4	
8	11210565	垫片	Plate	Y	4	
9	11210211	六角螺钉	Screw	Y	4	
10	11210203	平垫圈	Plain washer	Y	8	
11	11210102	六角螺栓	Hexagon screw	Y	4	
12	11210199	垫圈	Plain washer	Y	4	
13	11210099	六角螺钉	Hexagon screw	Y	18	
14	11220311	平垫圈	Plain washer	Y	18	

SDLG

排气系统 Exhaust




A0140-58-2520-002

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11220935	消声器	Air silencer	Y	1	
2	11220951	排气管	Exhaust pipe	Y	1	
3	11212302	排气管夹	Clamp	Y	1	
4	14402185	消声器支架	Bracket	Y	1	
5	11212303	U 形螺栓	U-bolt	Y	2	
6	11210130	六角螺母	Hexagon nut	Y	12	
7	11212283	六角螺钉	Hexagon screw	Y	4	
8	11210064	弹垫	Spring washer	Y	4	
9	11210197	垫圈	Plain washer	Y	4	


SDLG

燃油箱 Fuel tank




序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14402353	燃油箱总成	Fuel tank	Y	1
2	14402354	燃油箱体	Fuel tank	N	1
3	11210678	滤网	Strainer	Y	1
4	14400955	端盖	Cover	Y	1
5	11210070	O 形圈	O-ring	Y	1
6	11210197	垫圈	Plain washer	Y	1
7	11210122	六角螺钉	Hexagon screw	Y	1
8	11210752	滤网	Oil strainer	Y	1
9	11210523	排油阀	Valve	Y	1
10	11210052	垫片	Gasket	Y	1
11	11211124	垫片	Shim	Y	5
12	11210200	垫圈	Plain washer	Y	4
13	11211638	弹簧垫圈	Spring washer	Y	4
14	11210195	螺栓	Screw	Y	4
15	11210071	螺塞	Plug	Y	1
16	11210044	垫片	Gasket	Y	1
17	11210751	接头	Connector	Y	1
18	11210241	燃油箱呼吸器	Air filter	Y	1
19	14402347	端盖	Cover	Y	1
20	11210034	法兰螺钉	Flange screw	Y	2

燃油管路总成 Fuel supply system





序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11220487	接头	Nipple	Y	2
2	14402553	燃油管	Fuel hose	Y	1
3	14402554	燃油管	Fuel hose	Y	1
4	14402167	燃油管	Fuel hose	Y	1
5	11222299	软管	Hose	Y	2
6	14406567	燃油管	Fuel hose	Y	1
7	14402174	燃油管	Fuel hose	Y	1
8	11211714	防护层	Cover	Y	1
9	11221054	软管保护	Hose protection	Y	1
10	14402169	支架	Bracket	Y	1
11	14402172	支架	Bracket	Y	1
12	11221535	接头	Nipple	Y	1
13	14400342	扎带	Strip clamp	Y	2
14	11210473	管夹	Clip	Y	2
15	11219870	管夹	Clamp	Y	3
16	11210810	管夹	Clip	Y	7
17	11219923	橡胶套	Grommet	Y	1
18	11211642	管夹	Clamp	Y	2
19	11211711	平面垫圈	Plane gasket	Y	4
20	11210124	六角螺钉	Hexagon screw	Y	2
21	11210074	法兰螺钉	Flange screw	Y	1
22	11210197	垫圈	Plain washer	Y	2
23	11210033	法兰螺钉	Flange screw	Y	1
24	11210036	法兰螺钉	Flange screw	Y	14
25	11216523	平垫片	Gasket	Y	1
26	11216008	空心螺栓	Screw	Y	3
27	11218754	垫片	Shim	Y	6
28	14405778	燃油管	Fuel hose	Y	1
29	14402549	支架	Bracket	Y	1
30	11220488	阀	Valve	Y	1

燃油管路总成 Fuel supply system




油水分离器 Water separator





A0203-58-2350-012

油水分离器 Fuel filter w/o heater




A0203-58-2350-001

燃油加油泵及附件 Fuel filling pump



A0220-58-2344-006


散热器管路 Radiator connections



A0300-58-2610-003

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11218636	软管	Hose	Y	1
2	11221070	软管	Hose	Y	1
3	11220129	管	Hose	Y	2
4	11211714	防护层	Cover	Y	1
5	14407465	风扇护网	Fan guard	Y	1
6	14405834	散热器出水管	Hose	Y	1
7	14405833	发动机进水管	Hose	Y	1
8	14404461	发动机进水钢管	Pipe	Y	1
9	14402004	胶管	Hose	Y	1
10	14402005	胶管	Hose	Y	1
11	14404458	发动机出水钢管	Pipe	Y	1
12	11220950	拉杆	Tie plate	Y	2
13	11210098	六角螺钉	Hexagon screw	Y	4
14	11220311	平垫圈	Plain washer	Y	2
15	11210695	垫圈	Washer	Y	2
16	11220568	支架	Bracket	Y	2
17	11220564	支架	Bracket	Y	1
18	11210033	法兰螺钉	Flange screw	Y	3
19	11211136	卡箍	Hose clamp	Y	4
20	11211137	管夹	Hose clamp	Y	4
21	11210026	喉箍	Hose clamp	Y	5
22	11210027	喉箍	Hose clamp	Y	2
23	11211655	管夹	Insulating clip	Y	6
24	11210260	管夹	Clip	Y	2
25	14403848	膨胀水箱总成	Expansion tank	Y	1
26	11220100	支架	Bracket	Y	1
27	11210197	垫圈	Plain washer	Y	4
28	11210130	六角螺母	Hexagon nut	Y	2
29	11220104	减震器	Absorber	Y	2
30	11211894	卡簧	Clip	Y	2

散热器管路 Radiator connections




A0300-58-2610-003

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
31	11210034	法兰螺钉	Flange screw	Y	12	
32	11210036	法兰螺钉	Flange screw	Y	10	
33	11220517	液位传感器	Level sensor	Y	1	
34	14403850	水箱盖	Radiator cap	N	1	
35	14403851	压力水箱盖	Radiator cap	N	1	
36	14403849	膨胀水箱体	Expansion tank	N	1	


SDLG

散热器 Radiator




A0301-58-2610-005

中冷系统 Charge air cooler



A0302-58-2581-002

风扇 Fan and acc



A0303-58-2630-002


E 行走系统

TRAVEL SYSTEM



山东临工工程机械有限公司
SHANDONG LINGONG CONSTRUCTION MACHINERY CO.,LTD.

履带链条 Track chain




E0920-58-7753-171

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14401880	左链轨节	N	50	
2	14400960	右链轨节	N	50	
3	11213956	销	Y	49	
4	11213971	销	Y	1	
5	11214027	套	Y	49	
6	11214028	套	Y	1	
7	11213970	垫片	Y	2	
8	11213957	密封圈	Y	88	
9	11214036	螺栓	Y	200	
10	11220178	螺母	N	200	
11	14401271	履带板	N	50	
12	14401270	链轨总成	N	1	
13	14405916	履带	Y	2	


SDLG

履带导件 Track guard




E0920-58-7757-023

导向轮总成 Front idler




E0930-58-7751-011

支重轮总成 Track guard



E0940-58-7756-025

涨紧装置总成 Track tensioner




E0950-58-7758-014

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11219379	涨紧弹簧	Y	2	
2	11213958	螺母	Y	1	
3	11213960	活塞	Y	1	
4	11219380	缓冲弹簧	N	1	
5	11213963	挡板	Y	1	
6	11213965	安装板	Y	1	
7	11213966	行程限位套	Y	1	
8	11217650	履带张紧度调节缸	Y	1	
9	11217664	单向阀	Y	1	
10	11219117	轭	Y	1	
11	11210001	油杯	Y	1	
12	11210064	弹垫	Y	2	
13	11210122	六角螺钉	Y	2	


SDLG

托链轮 Sprocket




E0960-58-7755-009

驱动轮 Drive wheel



E0970-58-7752-007

行走马达盖板 Cover plate



E0980-58-7150-005


F 液压系统

HYDRAULIC SYSTEM



山东临工工程机械有限公司
SHANDONG LINGONG CONSTRUCTION MACHINERY CO.,LTD.


液压油箱总成 Hydraulic tank



F1010-58-9111-069


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14402349	液压油箱总成	Tank_assy hydraulic	Y	1
2	11210663	旁通阀	Valve	Y	1
3	11210664	弹簧	Spring	Y	1
4	11216973	滤芯	Filter insert	Y	1
5	11211189	液压回油滤芯	Hydraulic fluid filter	Y	1
6	14401299	吸油过滤器	Hydraulic fluid filter	Y	1
7	14401300	换气过滤器	Breather cap	Y	1
8	11210686	液位计	Gauge	Y	1
9	11210699	螺塞	Plug	Y	1
10	11210523	排油阀	Valve	Y	1
11	11210070	O 形圈	O-ring	Y	1
12	11210069	O 形圈	O-ring	Y	1
13	11210176	O 形圈	O-ring	Y	1
14	11210052	垫片	Gasket	Y	1
15	11210088	六角螺钉	Six point socket screw	Y	4
16	11210197	垫圈	Plain washer	Y	8
17	11210122	六角螺钉	Hexagon screw	Y	8
18	11211124	垫片	Shim	Y	5
19	11210200	垫圈	Plain washer	Y	4
20	11211638	弹簧垫圈	Spring washer	Y	4
21	11210195	螺栓	Screw	Y	4
22	14402351	液压油箱体	Tank_wa hydraulic	N	1
23	14400945	吸油法兰盘	Cover	Y	1
24	14400950	回油法兰盘	Cover	Y	1
25	14400947	吸油端盖	Cover	Y	1

工作泵系统 Hydraulic pump system




F1100-58-9112-036

液压泵 Hydraulic pump




F1100-58-9130-004

滤清器 Filter



F1201-58-9114-002

伺服系统 Servo system




F1201-58-9140-069

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11211697	堵头	Plug	Y	1	
2	11210133	O 形圈	O-ring	Y	1	
3	11211704	堵头	Plug	Y	5	
4	11210006	O 形圈	O-ring	Y	5	
5	11211669	弯管接头	Connector	Y	1	
6	11211024	堵头	Plug	Y	1	
7	11210007	O 形圈	O-ring	Y	1	
8	11210144	O 形圈	O-ring	Y	1	
9	11212977	堵头	Plug	Y	1	

SDLG


主阀到电磁阀管路总成 Control valve to solenoid valve



F1202-58-9140-055


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14404513	支架	Y	1	
2	11210603	橡胶圈	Y	1	
3	11210064	弹垫	Y	2	
4	11210398	护套	Y	1	
5	14400591	胶管	Y	1	
6	14401831	胶管	Y	1	
7	11211679	接头	Y	1	
8	11211674	接头	Y	1	
9	11211684	接头	Y	5	
10	11211685	接头	Y	2	
11	11211695	弯管接头	Y	1	
12	11211672	三通	Y	2	
13	11220221	接头	Y	1	
14	14401825	胶管	Y	1	
15	14402063	胶管	Y	1	
16	11211316	接头	Y	1	
17	11211694	弯管接头	Y	2	
18	11214122	弯管接头	Y	1	
19	11211704	堵头	Y	2	
20	11210006	O 形圈	Y	12	
21	11210007	O 形圈	Y	2	
22	11210133	O 形圈	Y	3	
23	11210135	O 形圈	Y	1	
24	11210166	O 形圈	Y	2	
25	14400333	胶管	Y	1	
26	11210034	法兰螺钉	Y	2	
27	11210122	六角螺钉	Y	2	
28	14402100	胶管	Y	1	
29	11210197	垫圈	Y	2	
30	14401838	胶管	Y	1	

主阀到电磁阀管路总成 Control valve to solenoid valve





F1202-58-9140-055

伺服系统 Servo system



F1203-58-9112-048

液压操纵总成 Hydraulic lines






F1220-58-9112-039

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14402542	钢管	Pipe	Y	1	
2	14400541	弯接头	Elbow nipple	Y	2	
3	11210151	内六角螺钉	Hex. socket screw	Y	12	
4	11210064	弹垫	Spring washer	Y	12	
5	11221586	o型圈	O-ring	Y	3	
6	14402541	胶管	Hose assembly_special	Y	1	
7	14402540	胶管	Hose assembly_special	Y	1	
8	14402538	钢管	Pipe	Y	1	
9	14402536	钢管	Pipe	Y	1	


SDLG

液压操纵总成 Hydraulic lines





F1220-58-9112-040

主阀装配总成 Main valve assembly



F1220-58-9120-016



主阀 Control valve



F1222-11214526-01

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11210144	O 形圈	O-ring	Y	6
2	11210047	O 形圈	O-ring	Y	4
3	11213831	堵头	Plug	N	12
4	11213822	垫圈	Washer	N	15
5	11221045	螺栓	Hex. socket screw	Y	7
6	11220908	阀杆端盖	Cover	Y	1
7	11218950	罩盖	Cover	Y	6
8	11221047	O型圈	O-ring	Y	7
9	11210157	六角螺钉	Hex. socket screw	Y	14
10	11210135	O 形圈	O-ring	Y	3
11	11211699	堵头	Plug	Y	2
12	11220382	堵头	Plug	Y	1
13	11219179	溢流阀	Relief valve	Y	1
14	11213825	O 形圈	O-ring	N	1
15	11211438	弹簧座	Spring seat	Y	1
16	11211455	弹簧	Spring	Y	1
17	11210145	O形圈	O-ring	Y	1
18	11210132	O 形圈	O-ring	Y	12
19	11210676	动臂保持阀阀体	Valve	Y	1
20	11213011	动臂保持阀阀体	Cover	N	1
21	11211969	阀芯	Control plunger	Y	1
22	11211971	弹簧	Spring	Y	1
23	11213012	螺栓	Bolt	N	4
24	11221051	螺栓	Hex. socket screw	Y	3
25	11210139	O形圈	O-ring	Y	3
26	11210166	O 形圈	O-ring	Y	7
27	11213010	阀芯	Piston	Y	1
28	11213014	阀芯座	Sleeve	N	1
29	11211968	阀芯	Control plunger	Y	1
30	11220975	堵头	Plug	Y	1


主閥 Control valve



F1222-11214526-01

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
31	11211972	弹簧	Y	1	
32	11211469	六角螺钉	Y	1	
33	11210131	O形圈	Y	1	
34	11211963	密封环	Y	1	
35	11211964	密封环	Y	1	
36	11220350	选择阀	Y	1	
37	11211467	堵头	Y	1	
38	11220395	螺栓	Y	3	
39	11210133	O 形圈	Y	2	
40	11210137	O形圈	Y	1	
41	11213022	o 型圈	N	1	
42	11220988	堵头	Y	1	
43	11213025	弹簧	N	1	
44	11213024	阀芯	Y	1	
45	11221044	螺栓	Y	5	
46	11211973	堵头	Y	1	
47	11221048	O型圈	Y	4	
48	11213833	主阀密封包	Y	1	


主阀 Control valve



F1222-11214526-02

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11210157	六角螺钉	Y	6	
2	11221016	单向阀	Y	1	
3	11213859	密封环	Y	1	
4	11211452	弹簧座	Y	3	
5	11221019	弹簧	Y	3	
6	11221021	限位套	Y	3	
7	11211453	弹簧座	Y	3	
8	11211448	螺栓	Y	3	
9	11221017	垫片	Y	1	
10	11213834	再生单向阀	Y	1	
11	11221018	弹簧	Y	1	
12	11219897	密封环	Y	1	
13	11213842	O型圈	Y	1	
14	11219901	堵头	Y	1	
15	11210133	O形圈	Y	1	
16	11211467	堵头	Y	1	
17	11211445	单向阀堵头	Y	3	
18	11211070	密封环	Y	5	
19	11210142	O形圈	Y	6	
20	11211454	弹簧	Y	5	
21	11211439	堵头	Y	1	
22	11210144	O形圈	Y	1	
23	11211460	弹簧	Y	1	
24	11210555	过载补油阀	Y	2	
25	11210008	O形圈	Y	1	
26	11211068	密封环	Y	1	
27	11210136	O形圈	Y	1	
28	11220393	阀杆	Y	1	
29	11211433	单向阀	Y	5	
30	11211468	锁定塞	Y	5	


主阀 Control valve



F1222-11214526-02


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
31	11220360	堵头	Y	1	
32	11221014	溢流阀	Y	1	
33	11210138	O形圈	Y	2	
34	11220358	阀芯	Y	1	
35	11220381	堵头	N	1	
36	11211955	堵头	Y	1	
37	11212999	弹簧	Y	1	
38	11220384	堵头	Y	1	
39	11213852	o 型圈	Y	1	
40	11220380	阀芯座	Y	1	
41	11220379	阀芯座	Y	1	
42	11220516	螺塞	Y	2	
43	11211432	单向阀	Y	2	
44	11211984	o 型圈	Y	1	
45	11211989	阀芯	Y	1	
46	11210137	O形圈	Y	2	
47	11219653	密封环	Y	1	
48	11211999	弹簧	Y	1	
49	11220389	弹簧	Y	1	
50	11211969	阀芯	Y	1	
51	11213051	o 型圈	Y	1	
52	11212002	密封环	Y	2	
53	11220374	阀芯	Y	1	
54	11211971	弹簧	Y	1	
55	11220378	阀芯座	Y	1	
56	11220138	阀芯	Y	1	
57	11210135	O 形圈	Y	1	
58	11211699	堵头	Y	1	
59	11220390	弹簧	Y	1	
60	11220375	阀芯	Y	1	

主阀 Control valve



F1222-11214526-02


主阀 Control valve



F1222-11214526-03

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11213057	弹簧	N	1	
2	11213883	活塞	N	1	
3	11213884	单向阀	N	1	
4	11211989	阀芯	Y	1	
5	11221019	弹簧	Y	4	
6	11221021	限位套	Y	4	
7	11211453	弹簧座	Y	4	
8	11211448	螺栓	Y	4	
9	11211452	弹簧座	Y	4	
10	11213005	堵头	N	1	
11	11210138	O形圈	Y	5	
12	11211069	密封环	Y	3	
13	11210144	O形圈	Y	1	
14	11220349	密封环	Y	1	
15	11213869	o型圈	Y	1	
16	11211975	密封环	Y	1	
17	11210134	O形圈	Y	1	
18	11220387	堵头	Y	1	
19	11210135	O形圈	Y	1	
20	11221020	阀杆挡板	Y	4	
21	11210157	六角螺钉	Y	8	
22	11221047	O型圈	Y	4	
23	11220377	阀芯座	Y	1	
24	11210555	过载补油阀	Y	1	
25	11210008	O形圈	Y	1	
26	11211068	密封环	Y	1	
27	11210136	O形圈	Y	1	
28	11213867	弹簧	N	1	
29	11213868	弹簧座	N	1	
30	11213872	阀芯	N	1	


主阀 Control valve



F1222-11214526-03

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
31	11220386	堵头	Y	1	
32	11221014	溢流阀	Y	1	
33	11213881	弹簧	Y	1	
34	11220358	阀芯	Y	1	
35	11220381	堵头	N	1	
36	11211955	堵头	Y	1	
37	11212999	弹簧	Y	1	
38	11213870	单向阀	N	1	
39	11213064	堵头	N	1	
40	11213834	再生单向阀	Y	1	
41	11221018	弹簧	Y	1	
42	11219897	密封环	Y	1	
43	11213842	O型圈	Y	1	
44	11219901	堵头	Y	1	
45	11219448	密封环	Y	1	
46	11213874	O型圈	Y	1	
47	11211454	弹簧	Y	2	
48	11220362	单向阀	Y	1	
49	11220974	螺母	Y	1	
50	11220352	堵头	Y	1	
51	11211468	锁定塞	Y	1	
52	11211070	密封环	Y	1	
53	11210142	O形圈	Y	1	
54	11220361	六角螺钉	Y	1	
55	11220366	阀体	Y	1	
56	11220365	阀芯	Y	1	
57	11213882	阀芯座	N	1	
58	11213833	主阀密封包	Y	1	


主阀 Control valve



F1222-11214526-04


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11220895	阀体	Y	1	
2	11220363	阀体	Y	1	
3	11221046	螺栓	Y	4	
4	11210144	O 形圈	Y	4	
5	11210166	O 形圈	Y	1	
6	11220359	弹簧座	Y	1	
7	11220367	弹簧	Y	1	
8	11212001	弹簧座	Y	1	
9	11210142	O 形圈	Y	6	
10	11211070	密封环	Y	6	
11	11220371	密封环	N	1	
12	11211439	堵头	Y	3	
13	11220139	堵头	Y	1	
14	11211445	单向阀堵头	Y	1	
15	11211468	锁定塞	Y	4	
16	11211454	弹簧	Y	4	
17	11211433	单向阀	Y	3	
18	11219500	堵头	Y	2	
19	11211432	单向阀	Y	2	
20	11219706	弹簧	Y	1	
21	11213890	阀芯	Y	1	
22	11213892	堵头	Y	1	
23	11210006	O 形圈	Y	1	
24	11210555	过载补油阀	Y	4	
25	11210008	O 形圈	Y	2	
26	11211068	密封环	Y	2	
27	11210136	O 形圈	Y	2	
28	11210783	备用联二级溢流阀	Y	1	
29	11222256	单向阀	Y	1	
30	11220369	单向阀	Y	1	

主阀 Control valve



F1222-11214526-04


伺服系统，控制阀到遥控阀 Servo system, control valve to remote control valve



F1221-58-9140-058


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11210905	阀体	Y	1	
2	11222270	阀	Y	1	
3	11210294	梭阀	Y	1	
4	11213172	管夹	Y	2	
5	11213173	海绵	Y	2	
6	11210330	护套	Y	2	
7	14405590	护套	Y	1	
8	14400601	胶管	Y	2	
9	14400534	胶管	Y	1	
10	11210034	法兰螺钉	Y	6	
11	11210127	六角螺钉	Y	2	
12	11210064	弹垫	Y	2	
13	11211685	接头	Y	4	
14	11211673	接头	Y	16	
15	11211315	接头	Y	2	
16	11210006	O 形圈	Y	4	
17	11210135	O 形圈	Y	18	
18	14400687	胶管	Y	1	
19	14400607	胶管	Y	1	
20	14400688	胶管	Y	4	
21	14400600	胶管	Y	2	
22	14400574	胶管	Y	1	
23	14401832	胶管	Y	2	
24	14401824	胶管	Y	1	
25	14400567	胶管	Y	2	
26	14400603	胶管	Y	2	
27	14400043	先导控制阀	Y	1	
28	14400042	先导控制阀	Y	1	

伺服系统，泵管线和过滤器安装件 Servo system, pump piping




序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11211669	弯管接头	Y	1	
2	14402766	胶管	Y	1	
3	14407100	胶管	Y	1	
4	11211674	接头	Y	2	
5	11210746	接头块	Y	1	
6	14402848	板	Y	1	
7	11210034	法兰螺钉	Y	8	
8	11211675	接头	Y	4	
9	11211701	堵头	Y	1	
10	11211317	弯管接头	Y	1	
11	11211013	测压接头	Y	3	
12	11211672	三通	Y	5	
13	11211694	弯管接头	Y	1	
14	11211691	弯管接头	Y	2	
15	11213249	弯管接头	Y	1	
16	11210133	O 形圈	Y	7	
17	11210006	O 形圈	Y	1	
18	11210141	O 形圈	Y	6	
19	11210166	O 形圈	Y	4	
20	11211982	o 型圈	Y	1	
21	11212036	弯管接头	Y	1	
22	11212035	接头	Y	1	
23	11210144	O 形圈	Y	1	
24	11211676	接头	Y	1	
25	11210009	O 形圈	Y	2	
26	11211696	弯管接头	Y	1	
27	11211687	接头	Y	1	
28	11211671	弯管接头	Y	1	
29	14402767	胶管	Y	1	
30	14402201	支架	Y	1	

伺服系统，泵管线和过滤器安装件 Servo system, pump piping



F1222-58-9140-056


伺服系统，控制阀管线 Servo system, control valve piping




F1223-58-9140-057

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11210922	梭阀	Y	1	
2	14402366	支架	Y	1	
3	11210032	法兰螺钉	Y	2	
4	11211026	三通	Y	1	
5	11211667	三通	Y	2	
6	11211670	三通	Y	1	
7	11211693	弯管接头	Y	1	
8	11211689	弯管接头	Y	8	
9	11211669	弯管接头	Y	3	
10	11211672	三通	Y	13	
11	11211676	接头	Y	1	
12	11214132	接头	Y	1	
13	11211666	接头	Y	1	
14	11210133	O 形圈	Y	26	
15	11210144	O 形圈	Y	1	
16	11210009	O 形圈	Y	1	
17	14401843	胶管	Y	1	
18	14400703	胶管	Y	1	
19	14400697	胶管	Y	1	
20	14400542	胶管	Y	1	
21	14400039	胶管	Y	2	
22	14400537	胶管	Y	1	
23	14402104	胶管	Y	2	
24	14401824	胶管	Y	1	
25	14400588	胶管	Y	2	
26	14400538	胶管	Y	1	
27	11215097	三通	Y	1	
28	14400331	胶管	Y	2	
29	14400598	胶管	Y	1	
30	14400814	胶管	Y	1	

伺服系统，控制阀管线 Servo system, control valve piping




伺服系统 Servo system



F1230-58-9140-123


先导控制阀 Control lever



F1260-14400042


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14400042	先导控制阀	Y	1	
2	11211597	固定板	Y	1	
3	11211510	垫圈	Y	2	
4	11211590	O形圈	Y	1	
5	11210244	六角螺钉	Y	2	
6	11211553	弹性销	Y	1	
7	11211593	衬套	Y	1	
8	11211596	固定板	Y	1	
9	11210252	阀芯	N	4	
10	11211511	推杆	N	2	
11	11211572	堵头	Y	4	
12	11211515	密封	Y	4	
13	11210137	O形圈	Y	4	
14	11211584	弹簧座	Y	2	
15	11211509	垫圈	Y	4	
16	11211583	弹簧座	Y	2	
17	11211512	推杆	N	2	
18	11211568	护套	Y	1	
19	11211589	先导阀阀体	N	1	
20	11210041	法兰螺钉	Y	8	
21	11210774	弹簧	Y	2	
22	11210432	弹簧	Y	2	
23	11211585	弹簧	Y	2	
24	11211586	弹簧	Y	2	
25	11211514	万向节	Y	1	
26	11211595	压盘	Y	1	
27	11211516	螺母	Y	1	
28	11211513	紧锁螺母	Y	1	
29	11211591	手柄总成	Y	1	
30	11211592	手柄头	Y	1	

先导控制阀 Control lever



F1260-14400042


先导控制阀 Control lever



F1270-14400043


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14400043	先导控制阀	Y	1	
2	11211597	固定板	Y	1	
3	11211510	垫圈	Y	2	
4	11211590	O形圈	Y	1	
5	11210244	六角螺钉	Y	2	
6	11211553	弹性销	Y	1	
7	11211593	衬套	Y	1	
8	11211596	固定板	Y	1	
9	11210252	阀芯	N	4	
10	11211511	推杆	N	2	
11	11211572	堵头	Y	4	
12	11211515	密封	Y	4	
13	11210137	O形圈	Y	4	
14	11211584	弹簧座	Y	2	
15	11211509	垫圈	Y	4	
16	11211583	弹簧座	Y	2	
17	11211512	推杆	N	2	
18	11211568	护套	Y	1	
19	11211589	先导阀阀体	N	1	
20	11210041	法兰螺钉	Y	8	
21	11210774	弹簧	Y	2	
22	11210432	弹簧	Y	2	
23	11211585	弹簧	Y	2	
24	11211586	弹簧	Y	2	
25	11211514	万向节	Y	1	
26	11211595	压盘	Y	1	
27	11211516	螺母	Y	1	
28	11211513	紧锁螺母	Y	1	
29	11211591	手柄总成	Y	1	
30	11210253	手柄头	Y	1	

先导控制阀 Control lever



F1270-14400043

液压装置 Extra hyd equipment




F1300-58-9160-054.20997

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221586	o型圈	O-ring	Y	2	
2	11210064	弹垫	Spring washer	Y	8	
3	11212046	内六角螺钉	Hex. socket screw	Y	8	
4	11211938	管夹	Clamp	Y	2	
5	11210067	弹垫	Spring washer	Y	2	
6	11210104	六角螺钉	Hexagon screw	Y	2	
7	11210197	垫圈	Plain washer	Y	4	
8	11210124	六角螺钉	Hexagon screw	Y	4	
9	14402444	钢管	Pipe	Y	1	
10	14402445	钢管	Pipe	Y	1	
11	14402446	胶管	Hose assembly	Y	2	
12	14408324	管夹	Clamp	Y	2	
13	14405755	管夹	Clamp	Y	2	

SDLG


工作液压,动臂油管 Working hydraulic system



F1300-58-9160-060.20997


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221586	O型圈	Y	5	
2	11210064	弹垫	Y	20	
3	14402515	钢管	Y	1	
4	14402578	钢管	Y	1	
5	14402579	钢管	Y	1	
6	14402513	钢管	Y	1	
7	14402509	钢管	Y	1	
8	14402511	钢管	Y	1	
9	11214154	管夹	Y	5	
10	11210067	弹垫	Y	13	
11	11210104	六角螺钉	Y	10	
12	11210105	六角螺钉	Y	2	
13	11210018	分体法兰	Y	8	
14	11210124	六角螺钉	Y	6	
15	14408327	管夹	Y	1	
16	14408326	管夹	Y	1	
17	11210197	垫圈	Y	1	
18	11211938	管夹	Y	7	
19	11210193	螺栓	Y	1	
20	14402582	胶管	Y	2	
21	14402580	胶管	Y	1	
22	14402581	胶管	Y	1	
23	14402583	胶管	Y	1	
24	14402584	胶管	Y	1	
25	11220507	O形圈	Y	2	
26	11213454	螺钉	Y	12	
27	11212056	管夹	Y	1	
28	11212046	内六角螺钉	Y	4	
29	14402609	钢管	Y	1	

液压装置 Extra hyd equipment




F1300-58-9160-062.20997

伺服系统 Servo system



F1301-58-9140-040


动臂油缸总成 Boom cylinder



F1314-58-9743-018

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14406062	动臂油缸	Lifting cylinder	Y	1
2	11214192	活塞杆	Rod	N	1
3	11221961	轴衬	Bushing	N	1
4	11211804	滑动轴套	Bushing	Y	1
5	11221962	活塞	Piston	N	1
6	11214189	缓冲	Cushion	Y	1
7	11211775	挡圈	Retaining ring	Y	1
8	11214764	紧固螺钉24T516605	Screw	Y	15
9	11211777	挡圈	Retaining ring	Y	1
10	11210659	垫圈24C008020	Washer	Y	1
11	11214190	锁紧螺母	Lock nut	Y	1
12	11214191	紧固螺钉	Screw	Y	1
13	11211781	防尘圈	Sealing	Y	1
14	11211779	挡圈	Sealing	Y	1
15	11211798	挡圈	Ring	Y	1
16	11211344	缓冲圈	Sealing	Y	1
17	11212270	密封环	Ring	Y	1
18	11212273	o 型圈	O-ring	Y	2
19	11212267	密封环	Ring	Y	1
20	11210179	O 形圈	O-ring	Y	1
21	11214194	密封环	Ring	Y	1
22	11212262	活塞密封圈	Piston seal	Y	1
23	11212269	磨损环	Wear ring	Y	2
24	11212271	纳污环	Sealing ring	Y	2
25	14401744	衬套90X105XL95	Bushing_pem bushing_90x105x195	N	1
26	14401745	衬套90X105XL105	Bushing_pem bushing_90x105x105	N	1
27	11210871	防尘圈24R309030	Sealing	Y	4
28	kongbai	kongbai	Kongbai	N	1
29	11214193	密封套件	Sealing kit	Y	1


斗杆油缸总成 Arm cylinder



F1324-58-9753-003

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14402484	斗杆油缸	Dipper arm cylinder	Y	1
2	11214211	活塞杆	Rod	Y	1
3	11214214	滑动轴套	Bushing	Y	1
4	11221963	盖	Cover	N	1
5	11219449	缓冲套	Cushion	Y	1
6	11221964	活塞	Piston	N	1
7	11214216	缓冲	Cushion	Y	1
8	11211339	定位销	Pin	Y	1
9	11214220	挡环	Retaining ring	Y	1
10	11214764	紧固螺钉24T516605	Screw	Y	15
11	11214221	密封环	Ring retainer	Y	1
12	11210659	垫圈24C008020	Washer	Y	1
13	11210724	锁紧螺母	Lock nut	Y	1
14	11210743	紧固螺钉	Screw	Y	1
15	11214223	密封圈	Sealing	Y	1
16	11214222	密封圈	Sealing ring	Y	1
17	11214213	挡环	Ring	Y	1
18	11214210	缓冲圈	Rubber ring	Y	1
19	11214227	密封环	Ring	Y	1
20	11214225	o 型圈	O-ring	Y	2
21	11214228	密封环	Ring	Y	1
22	11214224	o 型圈	O-ring	Y	1
23	11214212	密封环	Sealing ring	Y	2
24	11214217	活塞主密封	Sealing	Y	1
25	11214218	支撑环	Ring	Y	2
26	11214219	纳污环	Sealing ring	Y	2
27	11221967	缸筒	Tube	N	1
28	11214226	密封套件	Sealing kit	Y	1


铲斗油缸总成 Bucket cylinder



F1334-58-9755-002

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14402485	铲斗油缸	Y	1	
2	11214233	活塞杆	Y	1	
3	11211804	滑动轴套	Y	1	
4	11221961	轴衬	N	1	
5	11214189	缓冲	Y	1	
6	11221962	活塞	N	1	
7	11211775	挡圈	Y	1	
8	11214764	紧固螺钉24T516605	Y	15	
9	11211777	挡圈	Y	1	
10	11210659	垫圈24C008020	Y	1	
11	11214190	锁紧螺母	Y	1	
12	11214191	紧固螺钉	Y	1	
13	11211781	防尘圈	Y	1	
14	11211779	挡圈	Y	1	
15	11211798	挡圈	Y	1	
16	11211344	缓冲圈	Y	1	
17	11212270	密封环	Y	1	
18	11212273	o 型圈	Y	2	
19	11212267	密封环	Y	1	
20	11210179	O 形圈	Y	1	
21	11214194	密封环	Y	2	
22	11212262	活塞密封圈	Y	1	
23	11212269	磨损环	Y	2	
24	11212271	纳污环	Y	2	
25	11221965	缸筒	N	1	
26	11214193	密封套件	Y	1	


回转液压总成 Swing hydraulic system



F1410-58-9112-038.20581

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11210103	六角螺栓	Hexagon screw	Y	4	
2	11213454	螺钉	Hex. socket screw	Y	16	
3	11221586	o型圈	O-ring	Y	4	
4	11210064	弹垫	Spring washer	Y	16	
5	11210067	弹垫	Spring washer	Y	4	
6	14402499	胶管	Hose assembly	Y	1	
7	14402497	胶管	Hose assembly	Y	1	
8	14402496	胶管	Hose assembly	Y	1	
9	14402498	胶管	Hose assembly	Y	1	
10	11210199	垫圈	Plain washer	Y	4	
11	11210210	六角螺钉	Hexagon screw	Y	1	
12	11210196	螺母	Nut	Y	1	
13	11210144	O 形圈	O-ring	Y	4	
14	14400413	接头	Nipple	Y	2	
15	11210018	分体法兰	Flange	Y	8	
16	14400605	直接头	Nipple	Y	2	

回转马达减速机总成 Drive unit




F1420-58-4312-003

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14402195	回转马达	Drive unit_swing e6300f	Y	1
2	11214026	回转减速机	Transmission	Y	1
3	14402196	回转马达总成	Swing motor	N	1
4	11214085	挡环	Retaining ring	Y	1
5	11212218	油标管	Pipe	Y	1
6	11212219	油标尺	Gauge	Y	1
7	11210669	定位销	Pin	Y	1
8	11210200	垫圈	Plain washer	Y	14
9	11214072	六角螺钉	Hexagon screw	Y	14

SDLG


回转减速机 Swing gearbox



F1422-11214026


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11213974	齿轮轴	Y	1	
2	11213975	轴环	Y	1	
3	11213976	密封	Y	1	
4	11213977	轴承	Y	1	
5	11221969	减速机壳体	N	1	
6	11214020	密封	Y	1	
7	11213978	法兰盘	Y	1	
8	11210153	螺栓	Y	12	
9	11213979	轴承	Y	1	
10	11214069	挡圈	Y	1	
11	11214067	销轴	Y	4	
12	11213980	齿轮	Y	1	
13	11213990	二级行星架总成	Y	1	
14	11221970	行星齿轮架	N	1	
15	11213981	齿轮	Y	4	
16	11213982	轴衬	Y	4	
17	11212211	垫圈	Y	8	
18	11213983	行星销	Y	4	
19	11211660	弹性销	Y	7	
20	11213984	齿轮	Y	1	
21	11212204	垫片	Y	1	
22	11211404	密封环	Y	1	
23	11213985	一级行星架总成	Y	1	
24	11221971	行星齿轮架	N	1	
25	11213986	齿轮	Y	3	
26	11211383	滚针轴承	Y	3	
27	11213987	垫圈	Y	6	
28	11213988	行星轴	Y	3	
29	11210523	排油阀	Y	1	
30	11212206	垫板	Y	1	

回转减速机 Swing gearbox



F1422-11214026


回转马达总成 Swing motor



F1421-14402196

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11212221	端盖	Casing	Y	1
2	11212222	输出轴	Shaft	Y	1
3	11212223	柱塞	Control plunger	Y	2
4	11220997	弹簧	Spring	N	2
5	11212225	滚轴轴承	Roller bearing	Y	1
6	11212226	堵头	Plug	Y	2
7	11210508	溢流阀	Relief valve	Y	2
8	11210170	O形圈	O-ring	Y	1
9	11210416	六角螺钉	Screw	Y	3
10	11212227	柱塞	Piston	Y	9
11	11212438	堵头	Plug	Y	2
12	11212228	配流盘	Plate	Y	1
13	11212413	制动缸体	Piston	Y	1
14	11212426	九孔盘	Plate	Y	1
15	11212419	摩擦片	Plate	Y	3
16	11212420	摩擦片	Plate	Y	2
17	11212425	斜盘	Plate	Y	1
18	11212424	压盖	Cover	Y	3
19	11212421	弹簧	Spring	Y	20
20	11212427	弹簧	Spring	Y	1
21	11212436	O形圈	O-ring	Y	1
22	11212423	弹性挡圈	Ring	Y	1
23	11211547	螺栓	Bolt	Y	4
24	11212422	滚轴轴承	Roller bearing	Y	1
25	11212418	堵头	Plug	Y	3
26	11212412	密封	Sealing	Y	1
27	11210827	延时阀	Valve	Y	1
28	11212417	堵头	Plug	Y	2
29	11212429	堵头	Plug	Y	2
30	11212428	缸体	Cylinder	Y	1

回转马达总成 Swing motor




F1421-14402196

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
31	11212411	O形圈	O-ring	Y	1	
32	11220989	O形圈	O-ring	Y	1	
33	11212410	防摆阀总成	Valve	Y	1	
34	11210825	壳体	Casing	N	1	
35	11210820	堵头	Plug	Y	2	
36	11211554	O形圈	O-ring	Y	2	
37	11210624	O形圈	O-ring	Y	2	
38	11210703	O形圈	O-ring	Y	2	
39	11212439	螺栓	Screw	Y	4	
40	11220996	防摆阀	Valve	Y	2	
41	11210137	O形圈	O-ring	Y	1	
42	11219653	密封环	Sealing ring	Y	1	
43	11210145	O形圈	O-ring	Y	2	
44	11212430	回转马达密封件包	Sealing kit	Y	1	


SDLG

回转接头总成 Turning joint




F1420-58-4430-001

行走液压系统 Travel hydraulic system



F1500-58-9112-042

行走先导阀总成 Travel control valve assembly




F1500-58-9140-047

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11216751	手柄头	Knob	Y	1	
2	11216752	手柄头	Knob	Y	1	
3	14402164	脚踏板	Pedal	Y	1	
4	14402163	脚踏板	Pedal	Y	1	
5	11216661	橡胶套	Cover	Y	1	
6	11216660	橡胶套	Cover	Y	1	
7	11214283	先导控制阀	Pedal	Y	1	
8	14402359	先导操纵杆	Control lever	Y	1	
9	14402358	先导操纵杆	Control lever	Y	1	
10	11210218	垫圈	Washer	Y	2	
11	11210034	法兰螺钉	Flange screw	Y	4	
12	11210032	法兰螺钉	Flange screw	Y	4	
13	11210129	螺母	Hexagon nut	Y	2	
14	11210158	六角螺钉	Hex. socket screw	Y	4	


SDLG

主阀至行走先导阀管路总成 Servo system




F1510-58-9140-054

行走马达及减速机总成 Drive unit



F1511-58-4311-005.21892


行走减速机 Travel gearbox



F1515-14408561

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11214030	减速机壳体	Y	1	
2	11214000	齿轮	Y	1	
3	11211638	弹簧垫圈	Y	18	
4	11214826	螺栓	Y	19	
5	11222102	端盖	N	1	
6	11212148	堵头	Y	2	
7	11223101	轴承	Y	2	
8	11213998	压板	Y	1	
9	11213999	垫片	Y	1	
10	11219489	螺栓	Y	20	
11	11214001	三级行星架总成	Y	1	
12	11218926	调整垫片	Y	1	
13	11214005	行星轴	Y	5	
14	11214003	行星齿轮	Y	4	
15	11214004	垫圈	Y	8	
16	11211660	弹性销	Y	7	
17	11221958	垫圈	N	1	
18	11214002	滚针轴承	Y	4	
19	11214006	齿轮	Y	1	
20	11214008	二级行星架总成	Y	1	
21	11214012	行星轴	Y	3	
22	11218927	调整垫片	Y	1	
23	11214010	行星齿轮	Y	3	
24	11214011	垫圈	Y	6	
25	11218929	调整垫片	Y	1	
26	11214009	滚针轴承	Y	3	
27	11214015	垫圈	Y	1	
28	11214013	齿轮	Y	1	
29	11214031	三级行星架总成	Y	1	
30	11214007	环	Y	1	

行走减速机 Travel gearbox




F1515-14408561

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
31	11214032	齿轮	Gear	Y	1	
32	11210166	O 形圈	O-ring	Y	2	
33	11214067	销轴	Pin	Y	2	
34	11221959	挡圈	Retaining ring	N	1	
35	11223102	浮动油封	Sealing	Y	1	
36	11218928	调整垫片	Shim	Y	1	

SDLG


行走马达 Travel motor



F1514-14408649

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221947	阀芯总成	Y	1	
2	11213997	棒	Y	1	
3	11213996	销	Y	1	
4	11210136	O 形圈	Y	1	
5	11213874	O型圈	Y	1	
6	11213955	螺钉	Y	1	
7	11210109	六角螺母	Y	1	
8	11213992	定位销	Y	1	
9	11214076	O型圈	Y	2	
10	11214052	法兰端盖	Y	2	
11	11214056	螺钉	Y	1	
12	11210132	O 形圈	Y	1	
13	11211704	堵头	Y	7	
14	11210006	O 形圈	Y	7	
15	11221948	溢流阀	N	2	
16	11221690	螺丝	Y	2	
17	11210873	堵头	Y	9	
18	11218144	内六角螺钉	Y	8	
19	11221105	塞	N	2	
20	11211982	o 型圈	Y	2	
21	11210156	内六角螺钉	Y	4	
22	11214054	座圈	Y	2	
23	11214055	限位塞	Y	2	
24	11214038	钢球	Y	2	
25	11221785	铭牌	N	1	
26	11211953	六角螺钉	Y	2	
27	11214050	垫圈	Y	2	
28	11214051	弹簧	Y	2	
29	11214058	弹簧	Y	1	
30	11213949	垫片	Y	1	


行走马达 Travel motor



F1514-14408649


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
31	11214057	堵头	Y	1	
32	11210137	O形圈	Y	1	
33	11221949	阀芯	Y	1	
34	11213947	弹簧	Y	1	
35	11213948	堵头	Y	1	
36	11210135	O形圈	Y	1	
37	11222106	阀壳	N	1	
38	11213994	轴	Y	1	
39	11220907	滚轴轴承	Y	1	
40	11213935	轴承	Y	1	
41	11214812	密封环	Y	2	
42	11221950	壳体	N	1	
43	11214053	密封环	Y	1	
44	11221954	衬套	N	1	
45	11213936	枢轴	Y	2	
46	11213937	活塞	Y	1	
47	11213993	定位销	Y	5	
48	11213944	摩擦片	Y	3	
49	11213945	摩擦片	Y	2	
50	11213995	制动缸体	Y	1	
51	11214070	O型圈	Y	1	
52	11215438	O形圈	Y	1	
53	11214021	弹簧	Y	10	
54	11213938	斜盘	Y	1	
55	11222897	活塞缸体	Y	1	
56	11213939	弹簧	Y	9	
57	11213940	垫片	Y	1	
58	11213941	球面衬套	Y	1	
59	11213942	九孔盘	Y	1	
60	11221951	衬套	N	9	

行走马达 Travel motor



F1514-14408649

油散总成 Oil radiator assembly



F1600-58-9112-037

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14401895	钢管	Y	1	
2	14402419	钢管	Y	1	
3	14402420	钢管	Y	1	
4	14402532	钢管	Y	1	
5	14401418	胶管	Y	1	
6	14402421	胶管	Y	1	
7	14402422	胶管	Y	1	
8	11213801	联接管总成	Y	1	
9	11222291	阀	Y	1	
10	11222292	阀	Y	1	
11	11210019	分体法兰	Y	12	
12	11210065	弹垫	Y	40	
13	11210154	内六角螺钉	Y	32	
14	11214904	O型圈	Y	7	
15	14402429	支架	Y	1	
16	11210037	法兰螺钉	Y	2	
17	11210064	弹垫	Y	1	
18	11210130	六角螺母	Y	1	
19	11210214	六角螺钉	Y	1	
20	11210760	管夹	Y	1	
21	11210759	管夹	Y	1	
22	11210758	套环	Y	1	
23	11210051	O形圈	Y	2	
24	11210155	六角螺钉	Y	4	
25	11214814	弹性挡圈	Y	2	
26	11213808	螺栓	Y	4	
27	11210111	O形圈	Y	1	


H 工作装置

WORKING EQUIPMENT




山东临工工程机械有限公司
SHANDONG LINGONG CONSTRUCTION MACHINERY CO.,LTD.

工作装置附件 Pin install, arm 2.55m hd




H1700-58-9751-052/58-9751-166

工作装置,销连接 Pin-bucket



H1710-58-9251-173

工作装置连杆总成 Structure_linkage




H1720-58-9752-058/059/060

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14401868	轭	Y	1	
2	14401869	连杆	Y	1	
3	14401870	连杆	Y	1	
4	11210871	防尘圈24R309030	Y	6	
5	11214231	轴套	Y	4	
6	11210001	油杯	Y	4	
7	14401867	销轴	Y	1	
8	11210206	六角螺栓	Y	1	
9	11210109	六角螺母	Y	2	
10	11212106	垫片	Y	3	
11	11212105	垫片	Y	2	

SDLG

大臂与润滑脂配管 Boom and grease piping





H1730-58-9741-051/58-9741-048

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14406875	动臂总成	Y	1	
2	11212087	防尘圈	Y	2	
3	14401876	黄油软管	Y	1	
4	14401877	黄油软管	Y	2	
5	14401878	黄油软管	Y	2	
6	11210001	油杯	Y	5	
7	11210803	螺纹接头	Y	2	
8	11210802	螺纹接头	Y	8	
9	11211663	管夹	Y	4	
10	11211656	管夹	Y	2	
11	11211654	管夹	Y	3	
12	11210218	垫圈	Y	9	
13	11210117	六角螺栓	Y	6	
14	11210187	六角螺栓	Y	3	



SDLG

工作装置,销连接 Pin install-boom rear



H1730-58-9741-049


工作装置,销连接 Pin install-boom rear



H1730-58-9741-050

Working equipment	261	
-------------------	-----	---

工作装置附件 Structure, 2.55m arm hd




H1730-58-9751-054

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14401879	斗杆总成	Dipper arm	Y	1	
2	14401884	压盘	Cover	Y	2	
3	11210150	内六角螺栓	Hex. socket screw	Y	4	
4	11210064	弹垫	Spring washer	Y	4	
5	11210786	定位销	Pin	Y	4	
6	11210872	防尘圈	Sealing	Y	2	
7	11210871	防尘圈24R309030	Sealing	Y	2	
8	11214209	防尘圈	Sealing ring	Y	2	

SDLG

铲斗总成 Bucket assembly



H1800-2618000650


K 车架

FRAME




山东临工工程机械有限公司
SHANDONG LINGONG CONSTRUCTION MACHINERY CO.,LTD.

上架总成 Superstructure frame assembly



K2400-58-7185-008.20581


密封 Sealing



K2400-58-8314-012

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14406015	配重海绵	N	1	
2	14405668	框架海绵	N	1	
3	14401109	侧门海绵	N	1	
4	14406017	海绵	Y	1	
5	14405451	海绵	Y	1	
6	14406018	海绵	Y	1	
7	14406014	海绵	Y	1	
8	14405454	海绵	Y	1	
9	14406016	海绵	Y	1	
10	14405448	海绵	Y	2	
11	14405321	海绵	Y	1	
12	14405320	海绵	Y	1	
13	14405445	海绵	Y	1	
14	14405447	海绵	Y	1	
15	14401110	海绵	Y	1	
16	14401111	海绵	Y	1	
17	14405460	海绵	Y	2	
18	14401112	海绵	Y	2	


回转机构总成 Swing gear system



K2500-58-4920-003.20581


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11216867	回转支撑	Y	1	
2	14402194	润滑管	Y	1	
3	11215389	密封	Y	1	
4	11213959	垫圈	Y	31	
5	11214080	六角螺钉	Y	31	
6	11210001	油杯	Y	2	
7	11210666	定位销	Y	3	
8	11210847	黄油管接头	Y	1	
9	11210846	黄油管接头	Y	1	
10	11211654	管夹	Y	1	
11	11210036	法兰螺钉	Y	1	
12	11214078	螺栓	Y	40	
13	11214079	垫圈	Y	40	
14	14402666	盖	Y	2	
15	11220343	衬垫	Y	2	
16	11210034	法兰螺钉	Y	4	

下架 Lower frame




K2600-58-7181-004

X架护板 Protecting plate



K2601-2626001233

配重 Counter weight



K2800-58-7160-160

L 驾驶室系统


CAB GROUP



山东临工工程机械有限公司

SHANDONG LINGONG CONSTRUCTION MACHINERY CO.,LTD.

驾驶室 Cab system




L2900-58-8100-001

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14406836	驾驶室总成	Cab	N	1	
2	11210067	弹垫	Spring washer	Y	7	
3	11210057	垫圈	Washer	Y	4	
4	11210102	六角螺栓	Hexagon screw	Y	2	
5	11210060	垫圈	Washer	Y	7	
6	11210112	六角螺钉	Hexagon screw	Y	5	
7	11210088	六角螺钉	Six point socket screw	Y	2	
8	11210090	六角螺钉	Six point socket screw	Y	2	
9	14405199	驾驶室电气	Electric equipment	N	1	
10	14406705	驾驶室	Cab	Y	1	



驾驶室 Cab




L2901-14406705

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14406706	驾驶室框架	Cab framework	Y	1	
2	11210057	垫圈	Washer	Y	34	
3	11210088	六角螺钉	Six point socket screw	Y	16	
4	11210517	密封条	Weatherstrip	Y	1	
5	11210346	密封条	Weatherstrip	Y	1	
6	11210406	底端横条	Backing bar	Y	1	
7	11211048	密封条	Weatherstrip	Y	1	
8	11211047	密封条	Weatherstrip	Y	1	
9	11211045	密封条	Weatherstrip	Y	1	


SDLG

驾驶室 Cab




L2902-14406705

驾驶室 Cab



L2903-14406705


驾驶室 Cab



L2904-14406705

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11210538	垫圈	Y	1	
2	11214648	门锁撞针	Y	1	
3	14404926	罩	Y	1	
4	11210303	后锁橡胶壳	Y	1	
5	11210547	缓冲器	Y	1	
6	11214782	把手	Y	1	
7	11210302	锁	Y	1	
8	11210304	拉绳	Y	1	
9	11214598	防滑板	Y	1	
10	14404918	滑轨	Y	1	
11	14404919	滑轨	Y	1	
12	11210511	密封条	Y	1	
13	11210512	密封条	Y	1	
14	11210513	海绵堵头	Y	1	
15	11210514	海绵堵头	Y	1	
16	11210642	橡胶座	Y	2	
17	11219554	装饰板	Y	1	
18	11210326	橡胶塞	Y	3	
19	11210548	缓冲器	Y	1	
20	11210064	弹垫	Y	6	
21	14404916	扶手	Y	1	
22	11210123	六角螺钉	Y	6	
23	11210534	安全锤	Y	1	
24	14404915	支架	Y	1	
25	11210084	六角螺钉	Y	2	
26	11211624	六角螺钉	Y	4	
27	11214626	垫圈	Y	2	
28	11211041	垫圈	Y	4	
29	11211038	螺母	Y	4	
30	11211042	垫圈	Y	2	

驾驶室 Cab




L2904-14406705

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
31	11210094	六角螺钉	Hexagon screw	Y	2
32	11220321	U形销	Clevis pin	Y	2
33	11211054	开口销	Split pin	Y	2
34	11210024	垫圈	Washer	Y	10
35	11210118	法兰螺钉	Hexagon screw	Y	4
36	11210034	法兰螺钉	Flange screw	Y	2
37	11210037	法兰螺钉	Flange screw	Y	2
38	11210059	垫圈	Washer	Y	1
39	11210061	弹簧垫圈	Spring washer	Y	10
40	11210065	弹垫	Spring washer	Y	1
41	11210492	垫片	Shim	Y	2
42	11210491	橡胶垫	Pad	Y	2
43	11210660	海绵	Sponge	Y	2

SDLG

驾驶室 Cab




L2905-14406705

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11219556	盖板	Cover	Y	1	
2	11219557	盖板	Cover	Y	1	
3	11211166	左侧遮阳帘挂钩	Hook	Y	3	
4	14401556	挂钩	Hook	Y	3	
5	14403221	内饰板	Cab trim	Y	1	
6	11210085	六角螺钉	Six point socket screw	Y	6	
7	11219559	控制面板	Panel	Y	1	
8	14401406	卡扣	Clip	Y	3	
9	14404920	支架	Bracket	Y	1	
10	11219549	海绵	Sponge	Y	2	

SDLG


推拉窗 Slide window



L2921-14404917


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11210572	弹簧	Y	2	
2	14404928	前推拉窗	Y	1	
3	14400120	玻璃	Y	1	
4	11210307	橡胶挡块	Y	1	
5	11210308	橡胶挡块	Y	1	
6	11210309	橡胶挡块	Y	1	
7	11210310	橡胶挡块	Y	1	
8	11210755	销	Y	2	
9	11210311	轴套	Y	2	
10	11210312	拉杆	Y	2	
11	14404921	把手	Y	1	
12	14404922	把手	Y	1	
13	11210313	塑料接头	Y	4	
14	14404923	罩	Y	1	
15	14404924	罩	Y	1	
16	11220324	滚轴	Y	2	
17	11220325	滚轴	Y	2	
18	14404927	定位板	Y	1	
19	11210332	拉杆	Y	1	
20	11210333	拉杆	Y	1	
21	11210343	密封条	Y	2	
22	11210089	六角螺钉	Y	2	
23	11210084	六角螺钉	Y	14	
24	11210085	六角螺钉	Y	2	
25	11214771	法兰螺钉	Y	2	
26	11210095	六角螺钉	Y	4	
27	11211038	螺母	Y	2	
28	11214626	垫圈	Y	2	
29	11216307	垫圈	Y	2	
30	11210061	弹簧垫圈	Y	16	

推拉窗 Slide window



L2921-14404917


驾驶室门 Door



L2922-14404914

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11215922	车门	Y	1	
2	11214655	座套	Y	2	
3	11214657	海绵	Y	2	
4	11214654	垫片	Y	2	
5	11210298	门后锁U形钩	Y	1	
6	14404925	罩	Y	1	
7	11210299	把手	Y	1	
8	11210300	门锁	Y	1	
9	11210301	门锁拉杆	Y	1	
10	11210318	玻璃存放器	Y	1	
11	11210319	玻璃存放器	Y	1	
12	14401343	玻璃	Y	1	
13	11210356	密封条	Y	1	
14	11210219	螺母	Y	2	
15	11210452	锁紧垫片	Y	1	
16	11210093	六角螺钉	Y	2	
17	11211051	六角螺钉	Y	2	
18	11211039	螺母	Y	2	
19	11214653	垫片	Y	2	
20	11210057	垫圈	Y	3	
21	11214768	垫圈	Y	4	
22	11214656	螺钉	Y	2	
23	11210062	弹簧垫圈	Y	3	
24	11210063	弹簧垫圈	Y	2	
25	11211046	密封条	Y	1	
26	11210472	密封条	Y	1	
27	11210084	六角螺钉	Y	6	
28	11210088	六角螺钉	Y	3	
29	14401344	推拉窗	Y	1	
30	11210653	门窗框架	N	1	

驾驶室门 Door




L2922-14404914

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
31	14400113	玻璃	Glass	Y	1	
32	14400115	玻璃	Glass	Y	1	
33	11210518	密封条	Weatherstrip	Y	1	
34	11210658	玻璃锁	Lock	Y	1	
35	11210655	玻璃限位	Lock catch	Y	1	
36	11210470	密封条	Sealing	Y	1	
37	11210654	框架	Frame	Y	1	
38	11210656	止动螺钉	Rubber stop	Y	1	
39	11219560	旋钮	Knob	Y	1	


SDLG

后视镜 Rear view mirror




L2940-58-8416-006

内部遮阳板 Sun visor




L2950-58-8600-001

遮阳板 Sun visor



L2950-58-8600-003


仪表盘 Instruction panel assembly



L2960-58-8810-001

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11217782	板	Cover	Y	1	
2	11217783	板	Cover	Y	1	
3	11217780	板	Cover	Y	1	
4	11210650	网兜	Net	Y	1	
5	14401400	上盖板	Cover	Y	1	
6	14401399	盖板	Cover	Y	1	
7	14401942	支架	Support	Y	1	
8	11210335	旋钮	Knob	Y	4	
9	11210336	旋钮	Knob	Y	3	
10	11210337	旋钮	Knob	Y	2	
11	14401941	盖板	Cover	Y	1	
12	11210339	杯架	Cup holder	Y	1	
13	11212910	垫板	Floor mat	Y	1	
14	14402468	支架	Support	Y	1	
15	11210033	法兰螺钉	Flange screw	Y	5	
16	11210034	法兰螺钉	Flange screw	Y	2	
17	11210117	六角螺栓	Hexagon screw	Y	2	
18	14401938	盖	Cover	Y	1	

座椅 Driver seat





L3000-58-8520-002

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14402622	座椅	Driver s seat	Y	1	
2	14402623	机械悬浮机构总成	Seat support	Y	1	
3	11210149	内六角螺钉	Hex. socket screw	N	4	
4	11214768	垫圈	Washer	Y	4	
5	11210063	弹簧垫圈	Spring washer	Y	4	
6	11210039	法兰螺钉	Flange screw	Y	2	
7	11210280	挡块	Bracket	Y	1	
8	11214757	法兰螺钉	Screw	Y	2	
9	11210147	内六角螺钉	Hex. socket screw	Y	8	
10	11210126	六角螺钉	Hexagon screw	Y	2	
11	11212281	垫圈	Washer	Y	2	
12	11210064	弹垫	Spring washer	Y	2	

SDLG


带安装零件的驾驶座 Operator seat with fitting parts



L3013-14402622

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11211359	头枕	Y	1	
2	4190003559004	右扶手组件187502	Y	1	
3	11210834	扶手	N	1	
4	11210843	座椅安全带	Y	1	
5	11210521	靠背	N	1	
6	11210522	座垫	N	1	
7	11210441	安全带	N	1	
8	11210754	滑槽	Y	1	
9	11210445	座椅右滑轨	Y	1	
10	11210446	护套	N	1	
11	11210502	操纵杆	N	1	
12	11210503	操纵杆	N	1	
13	11210757	支座	N	1	
14	11210262	钢丝绳	N	1	
15	11210571	把手	N	1	
16	11210509	压扣	N	1	
17	11210585	阻尼器	Y	1	
18	11210451	调节器	N	1	
19	11210745	护套	N	1	
20	11210448	座椅左滑轨	Y	1	
21	11210039	法兰螺钉	Y	2	
22	11214768	垫圈	Y	4	
23	11210063	弹簧垫圈	Y	4	
24	11210149	内六角螺钉	N	4	
25	11210147	内六角螺钉	Y	8	
26	11214757	法兰螺钉	Y	2	
27	11210280	挡块	Y	1	
28	11210126	六角螺钉	Y	2	
29	11210064	弹垫	Y	2	
30	11212281	垫圈	Y	2	


驾驶室地板 Cab floor



L3100-58-8110-001/58-8510-001


序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14400135	底板焊接总成	Base plate	Y	1	
2	11216133	左踏脚套	Cover	Y	1	
3	14401932	左脚踏上支架	Bracket	Y	1	
4	14401930	左脚踏下支架	Bracket	Y	1	
5	11210279	密封块	Sealing	Y	2	
6	14401933	减震器	Absorber	Y	5	
7	11210067	弹垫	Spring washer	Y	5	
8	11210060	垫圈	Washer	Y	5	
9	11210109	六角螺母	Hexagon nut	Y	5	
10	11210037	法兰螺钉	Flange screw	Y	28	
11	11210063	弹簧垫圈	Spring washer	Y	2	
12	11214768	垫圈	Washer	Y	2	
13	11210148	内六角螺钉	Hex. socket screw	Y	2	
14	11210036	法兰螺钉	Flange screw	Y	4	
15	11210475	海绵	Sponge	Y	1	
16	14400134	垫皮	Floor mat	Y	1	

驾驶室地板 Cab floor




L3100-58-8110-002

海绵组件 Sealing




L3100-58-8314-001

空调单元 Air conditioning system



L3110-58-8700-001


仪表盘控制板 Instruction panel assembly



L3200-58-8810-002


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11214476	骨架	Y	1	
2	11214478	右操纵箱支架	Y	1	
3	11219169	罩	Y	1	
4	11217784	右下壳体	Y	1	
5	11219170	盖	Y	1	
6	11217787	上壳体	Y	1	
7	14401398	罩盖	Y	2	
8	14401401	盖板	Y	1	
9	14401402	盖板	Y	1	
10	11218471	盖板	Y	1	
11	11212907	保险丝盒盖	Y	1	
12	11210341	安全锁定手柄	Y	1	
13	11210342	支座	Y	1	
14	11210344	底座	Y	1	
15	11217785	左出风箱盖	Y	1	
16	11217786	右出风箱盖	Y	1	
17	11210345	烟灰缸框	Y	1	
18	14401937	烟灰盘	Y	1	
19	11210546	衬套	Y	4	
20	11214776	法兰螺钉	Y	1	
21	11210088	六角螺钉	Y	4	
22	11210090	六角螺钉	Y	1	
23	11210096	六角螺钉	Y	2	
24	11214771	法兰螺钉	Y	3	
25	11210036	法兰螺钉	Y	2	
26	11210037	法兰螺钉	Y	3	
27	11217508	法兰螺栓	Y	4	
28	11214757	法兰螺钉	Y	10	
29	11211052	锁紧螺母	Y	1	
30	11211053	锁紧螺母	Y	2	

仪表盘控制板 Instruction panel assembly



L3200-58-8810-002


空调冷却和加热器 Air conditioning system



L3500-11220328

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11210466	橡胶垫	Y	4	
2	11215384	管	N	4	
3	11210369	壳体	Y	1	
4	11217630	壳体	N	1	
5	11219756	壳体	N	1	
6	11219761	壳体	Y	1	
7	11219759	橡胶块	Y	1	
8	11219758	橡胶块	Y	1	
9	11220331	接头	Y	2	
10	11219757	橡胶块	Y	1	
11	11210388	暖风水管	Y	1	
12	11210389	暖风水管	Y	1	
13	11220332	支架	N	1	
14	11215383	夹	Y	1	
15	11220333	箱	N	2	
16	11210383	导向机构	Y	1	
17	11212719	鼓风机马达	Y	1	
18	11214372	马达	Y	1	
19	11214371	马达	Y	3	
20	11210381	致动器	N	1	
21	11222254	传感器	Y	1	
22	11210378	橡胶套	Y	1	
23	11210377	调节风门	Y	1	
24	11210376	操纵杆	Y	1	
25	11210375	调节风门	Y	1	
26	11210372	调节风门	Y	1	
27	11210373	操纵杆	Y	1	
28	11210394	调节风门	Y	1	
29	11210395	调节风门	Y	1	
30	11214375	蒸发器	Y	1	

空调冷却和加热器 Air conditioning system




L3500-11220328

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
31	11210370	阀	Expansion valve	Y	1	
32	11214374	管	Pipe	Y	1	
33	14403810	空调主滤器	Air filter	Y	1	
34	11210698	散热器	Radiator	Y	1	
35	11210384	拉杆	Rod	Y	1	
36	11210385	联轴结	Rod	Y	1	
37	11210374	操纵杆	Control lever	Y	1	
38	11210371	调节风门	Door	Y	1	
39	11220335	线束	Wire	Y	1	



标志与标识 Sign and logo



L3600-58-8970-002.21986

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14402122	驾驶室标识包	Y	1	
2	14406234	紧急出口标识	Y	1	
3	14401685	油门旋钮标识	Y	1	
4	11210675	标签	Y	1	
5	11219880	标签	Y	1	
6	14401701	操作模式注意标识	Y	1	
7	14400001	注意阅读说明书标识	Y	1	
8	14406094	离开机器安全锁定杆禁止开启标识	Y	1	
9	14400003	注意锁好前窗标识	Y	1	
10	14406095	不要反拧反冲弹簧标识	Y	1	
11	14406233	禁止插入钥匙标识	Y	1	
12	14406093	视野扭曲警告标识	Y	1	
13	14406149	注意高压电线标识	Y	1	
14	14406096	注意碰撞标识	Y	1	
15	14400092	DECAL_CAB-LH	Y	1	
16	14403814	油水分离器放水标识	Y	1	
17	14404418	自动手动标识	Y	1	
18	14404997	紧急停止标识	Y	1	
19	14404521	油水分离器指示标识	Y	1	
20	14408156	电控发动机使用注意标识	Y	1	


M 覆盖件系统

COVER SYSTEM



山东临工工程机械有限公司
SHANDONG LINGONG CONSTRUCTION MACHINERY CO.,LTD.


机罩总成 Engine bonnet assembly



M3300-58-8222-007.20581


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14408184	机罩框架总成	Y	1	
2	14406618	左前框架	N	1	
3	14406352	左前框架	N	1	
4	14402235	海绵	Y	1	
5	14400393	海绵	Y	1	
6	11211125	海绵扣	Y	15	
7	14407048	右后框架	N	1	
8	14407050	左后支板	N	1	
9	14407051	左后支板	N	1	
10	14405864	海绵	Y	1	
11	14407054	左侧梁	N	1	
12	14407049	右侧梁	N	1	
13	11217606	后挡板	Y	1	
14	11221968	挡板	N	1	
15	11218978	海绵	Y	1	
16	14408185	上隔板总成	Y	1	
17	14408186	上隔板	Y	1	
18	14401864	海绵	Y	1	
19	14408187	海绵	Y	1	
20	11217608	前下挡板	Y	1	
21	11221966	挡板	N	1	
22	11218980	海绵	Y	1	
23	14402237	框架侧梁	Y	1	
24	14400961	盖板	Y	1	
25	11210501	卡板	Y	3	
26	11210507	海绵	Y	4	
27	11210538	垫圈	Y	40	
28	11210098	六角螺钉	Y	40	
29	11211123	垫圈	Y	4	
30	11210099	六角螺钉	Y	11	

机罩总成 Engine bonnet assembly



M3300-58-8222-007.20581


发动机机罩 Engine bonnet system



M3300-58-8226-100.20580

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14401310	盖板	Y	1	
2	14401311	盖板	Y	1	
3	14401312	机罩顶门	Y	1	
4	14401313	机罩支框	Y	1	
5	11218081	板	Y	1	
6	11218082	板	Y	1	
7	11218083	板	Y	1	
8	14401314	支架	Y	1	
9	14401315	机罩扶手	Y	1	
10	14401316	夹紧板	Y	2	
11	14401317	锁拉钩	Y	2	
12	11210403	拉杆	Y	1	
13	14401333	机罩合页	Y	2	
14	14406069	支架	N	1	
15	11210099	六角螺钉	Y	7	
16	14401336	机罩扶手	Y	1	
17	14401337	夹紧板	Y	2	
18	14401338	夹紧板	Y	2	
19	11212633	缓冲器	Y	4	
20	14401352	夹紧板	Y	2	
21	11214286	导向块	Y	1	
22	11212634	导向块	Y	1	
23	14401353	垫片	Y	1	
24	11210129	螺母	Y	4	
25	11210538	垫圈	Y	29	
26	11210098	六角螺钉	Y	24	
27	11210218	垫圈	Y	30	
28	11210063	弹簧垫圈	Y	4	
29	11210119	六角螺钉	Y	20	
30	11220311	平垫圈	Y	4	

发动机机罩 Engine bonnet system




M3300-58-8226-100.20580

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
31	14406065	发动机罩	Hood	Y	1
32	11211053	锁紧螺母	Lock nut	Y	4
33	11212647	六角螺钉	Hexagon screw	Y	10
34	11212648	垫圈	Plain washer	Y	4
35	11221040	开口销	Split pin	N	1
36	11211629	锁紧螺母	Lock nut	Y	4
37	11210578	缓冲块	Bushing	Y	2
38	11218085	支架	Bracket	Y	1
39	11218086	支架	Bracket	Y	2
40	11218084	海绵	Sponge	Y	1
41	14406066	海绵	Sponge	Y	1
42	14406064	海绵	Sponge	Y	1
43	14406067	海绵	Sponge	Y	1
44	11221856	帽	Cap	Y	27


SDLG

左罩总成 Hood




M3330-58-8226-008

上盖板总成 Cover



M3350-58-8222-014


机罩工具箱 Hoods and covers



M3400-58-8226-119


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14400862	箱体	Y	1	
2	14405709	工具箱	Y	1	
3	14402076	支架	Y	1	
4	14402077	支架	Y	1	
5	11210034	法兰螺钉	Y	11	
6	11211123	垫圈	Y	4	
7	14400864	缓冲块	Y	1	
8	14405708	工具箱盖	Y	1	
9	11210437	气弹簧	Y	1	
10	11210577	螺栓	Y	2	
11	11210526	长挂锁	Y	2	
12	11210527	垫片	Y	2	
13	11210440	堵头	Y	4	
14	11210525	缓冲块	Y	2	
15	11210120	六角螺栓	Y	8	
16	11210218	垫圈	Y	16	
17	11211053	锁紧螺母	Y	10	
18	11210197	垫圈	Y	8	
19	11211122	垫片	Y	2	
20	11210124	六角螺钉	Y	6	
21	11211629	锁紧螺母	Y	8	
22	11212648	垫圈	Y	8	
23	14405715	工具箱	Y	1	
24	14401257	工具箱盖	Y	1	
25	14402075	支架	Y	2	
26	11210100	六角螺钉	Y	4	
27	11210065	弹垫	Y	4	
28	11210098	六角螺钉	Y	4	
29	11210538	垫圈	Y	8	
30	11210032	法兰螺钉	Y	4	

机罩工具箱 Hoods and covers




M3400-58-8226-119

扶栏 Hand rail




M3400-58-8270-045

后视镜 Rear view mirror




M3400-58-8416-002

防滑垫 Slip protection



M3400-58-8910-046

盖板总成 Cover




M3430-58-8222-102.20581

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14401286	泵盖板	Cover	Y	1	
2	14402084	泵盖板	Cover	Y	1	
3	14401288	泵盖板	Cover	Y	1	
4	14401258	泵盖板	Cover	Y	1	
5	14407286	主泵盖板	Cover	Y	1	
6	14402083	泵盖板	Cover	Y	1	
7	11210538	垫圈	Washer	Y	16	
8	11210098	六角螺钉	Hexagon screw	Y	16	


SDLG

盖板总成 Cover




M3430-58-8370-059

盖板总成 Cover




M3430-58-8600-007

铭牌 Decal_sdlg_plant




M3600-58-8970-006

标志与标识 Decal




序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11210231	标签	Y	4	
2	14400007	规避高温烫伤标识	Y	1	
3	14400008	加注防冻液标识	Y	1	
4	14400278	SDLG品牌标志-黑	Y	2	
5	14400517	标签	Y	1	
6	14400523	电池爆炸警告标识	Y	1	
7	14400524	规避风扇伤害标识	Y	1	
8	14400777	防冻液加注注意标识	Y	1	
9	14401687	高温液体注意标识	Y	1	
10	14401693	行驶方向标识	Y	2	
11	14401695	安全带警示标识	Y	1	
12	14401697	蓄电池断开标识	Y	1	
13	14401703	电瓶箱注意标识	Y	1	
14	14401704	燃油箱禁止明火标识	Y	1	
15	14405100	侧面灰贴	Y	1	
16	14405514	吊装示意图	Y	1	
17	14405535	E6300F机型标识	Y	2	
18	11210399	标签	Y	1	
19	11210584	标签	Y	1	
20	14406236	禁止踩踏标识（宽70）	Y	1	
21	14406097	爆炸警告标识	Y	1	
22	11212833	印花	Y	2	
23	14406232	注意跌落标识	Y	1	
24	11210229	标签	Y	4	
25	14401696	46#液压油标识	Y	1	
26	14405536	标识包	Y	1	

标志与标识 Sign and logo




M3600-58-8970-030

标志与标识 Sign and logo



M3600-58-8970-031

标识标志 Decal



M3600-58-8970-025/041/035/040/016

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14405946	润滑示意图	Decal	Y	1	
2	14406237	禁止踩踏标识 (宽100)	Decal	Y	1	
3	11220949	标识	Decal	Y	1	
4	14401696	46#液压油标识	Decal	Y	2	
5	14405934	SDLG 3D品牌标识	Decal	Y	1	
6	14405935	左反光警示标识	Decal	Y	1	
7	14405936	右反光警示标识	Decal	Y	1	
8	14400773	SDLG品牌标志-黑	Decal	Y	1	



N 空调系统


AIR CONDITIONER SYSTEM



山东临工工程机械有限公司

SHANDONG LINGONG CONSTRUCTION MACHINERY CO.,LTD.


空调系统 Air conditioning system



N3510-58-8700-004

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14402470	压缩机	Y	1	
2	11210258	管夹	Y	2	
3	11210286	传感器	Y	1	
4	11214785	管夹	Y	11	
5	11222788	接头	Y	1	
6	11210410	排水胶管	Y	1	
7	11210413	管夹	Y	4	
8	11214297	支架	Y	1	
9	11210603	橡胶圈	Y	2	
10	11210613	支架	Y	1	
11	11210741	支架	Y	1	
12	11210794	调节器	Y	1	
13	11220934	吸入软管	Y	1	
14	11214357	空调高压胶管	Y	1	
15	14405924	空调管	Y	1	
16	14403219	冷凝器	Y	1	
17	11220574	支架	Y	1	
18	11211060	管夹	Y	1	
19	11212712	空调暖水管	Y	1	
20	11220966	暖风管	Y	1	
21	14402462	V带	Y	1	
22	11210205	六角螺钉	Y	1	
23	11210029	法兰螺母	Y	4	
24	11214756	法兰螺钉	Y	2	
25	11210034	法兰螺钉	Y	7	
26	11210036	法兰螺钉	Y	17	
27	11210064	弹垫	Y	2	
28	11210150	内六角螺栓	Y	1	
29	11210037	法兰螺钉	Y	1	
30	11210115	锁紧螺母	Y	1	

空调系统 Air conditioning system




N3510-58-8700-004

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
31	11210896	弯接头	Nipple	Y	2	
32	11211713	密封垫	Gasket	Y	1	
33	14401887	支架	Support	Y	2	
34	11210032	法兰螺钉	Flange screw	Y	2	
35	14405930	支架	Bracket	Y	1	
36	14407082	支架	Bracket	Y	1	

SDLG

冷凝器 Condenser




N3511-14403219

P 电气系统
ELECTRIC SYSTEM



山东临工工程机械有限公司
SHANDONG LINGONG CONSTRUCTION MACHINERY CO.,LTD.


驾驶室电气 Cab electric system



P4300-14405199

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11210728	天线	Y	1	
2	11210540	马达橡胶盖	Y	3	
3	11215639	点烟器	Y	1	
4	14400345	室内灯	Y	1	
5	14403759	喇叭	Y	2	
6	11210777	发动机控制盘	Y	1	
7	11210288	软管	Y	2	
8	14404976	驾驶室线束	Y	1	
9	11216208	刮雨器马达	Y	1	
10	11216209	刮雨器连杆	Y	1	
11	14400348	上雨刷片	N	1	
12	11218695	罩	Y	1	
13	14400349	上限位开关	N	1	
14	11219487	玻璃水阀	Y	1	
15	11216668	喷水头	Y	1	
16	14400346	上雨刮片支架	N	1	
17	11210477	天线线束	Y	1	
18	11214613	出气口	Y	5	
19	14400385	翘板开关线束	Y	1	
20	11210622	接头	Y	1	
21	11214616	十字凹口螺钉	Y	2	
22	11211620	六角螺钉	Y	3	
23	11214626	垫圈	Y	2	
24	11211644	管夹	Y	2	
25	11210024	垫圈	Y	9	
26	11210057	垫圈	Y	4	
27	11210061	弹簧垫圈	Y	5	
28	11210087	六角螺钉	Y	4	
29	11210083	螺钉	Y	4	
30	11210085	六角螺钉	Y	3	

驾驶室电气 Cab electric system




P4300-14405199

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
31	11211127	玻璃水管	Hose	Y	1	
32	11211050	玻璃水管	Hose	Y	1	
33	14401340	风口	Air outlet	Y	2	
34	11214781	箍带	Clamp	Y	6	
35	11219548	橡胶垫	Rubber mat	Y	1	
36	11217587	扎带	Cable tie	Y	2	
37	14400347	橡胶套	Rubber sleeve	Y	1	
38	11210062	弹簧垫圈	Spring washer	Y	4	
39	11210086	螺钉	Six point socket screw	Y	8	
40	11216307	垫圈	Spring washer	Y	2	

SDLG


电池与安装系统 Battery and mounting



P3700-58-3100-002


序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14400530	蓄电池	Wet battery	Y	2	
2	11210204	六角螺钉	Hexagon screw	Y	3	
3	11214946	垫圈	Washer	Y	3	
4	11210065	弹垫	Spring washer	Y	3	
5	11220566	支架	Bracket	Y	1	
6	11214403	支架	Bracket	Y	1	
7	14400668	电池盖	Battery cover	Y	1	
8	11212281	垫圈	Washer	Y	4	
9	11210122	六角螺钉	Hexagon screw	Y	4	

电源电气系统 Electrical assembly-power




P3700-58-3714-002

电源外接插头 Cable joint




P3710-58-2142-001

钥匙 Cotter



动臂线束 Boom cable(e6300)




P4100-58-3500-004

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11214261	动臂灯线束	Wiring harness	Y	1	
2	14400474	工作灯	Work lamp	Y	1	
3	14401815	支架	Bracket	Y	1	
4	11210257	管夹	Clip	Y	8	
5	11210537	接插件固定夹	Clip	Y	1	
6	11210036	法兰螺钉	Flange screw	Y	1	
7	11210042	法兰螺钉	Flange screw	Y	4	
8	11210060	垫圈	Washer	Y	1	
9	11210067	弹垫	Spring washer	Y	1	
10	11210101	六角螺钉	Hexagon screw	Y	1	


SDLG

工作灯 Work lamp




P4100-58-3500-014

喇叭 Horn



P4100-58-3621-001


主线束总成 Main cable harness



P4100-58-3710-009.20581



序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14408093	E6300F主线束	Y	1	
2	11210257	管夹	Y	1	
3	11210398	护套	Y	1	
4	11210408	套环	Y	1	
5	11210414	套环	Y	1	
6	11210537	接插件固定夹	Y	6	
7	11210618	套环	Y	1	
8	11212308	索环	Y	1	
9	14400340	扎带座	Y	6	
10	11214599	接插件固定夹	Y	3	
11	11210032	法兰螺钉	Y	15	
12	11210034	法兰螺钉	Y	10	
13	11210036	法兰螺钉	Y	6	
14	11210085	六角螺钉	Y	1	
15	11212648	垫圈	Y	1	
16	11211808	橡胶套	Y	2	
17	14400341	扎带	Y	12	
18	14400342	扎带	Y	21	
19	11219874	螺栓	Y	4	
20	11210089	六角螺钉	Y	2	
21	11211133	接插件固定夹	Y	1	
22	11210603	橡胶圈	Y	2	
23	14405801	支架	Y	1	
24	14400370	扎带	Y	1	

电子传感器 Sensor





P4100-58-3860-002

开关 Switch




P4101-58-3690-001

电子装置 Electronic unit



P4102-58-3670-003


开关 Switch



P4103-58-3640-007


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11210270	翘板开关总成	Y	2	
2	11217726	安全杆	Y	1	
3	11211616	六角螺钉	Y	1	
4	11210275	衬套	Y	1	
5	11211618	六角螺钉	Y	1	
6	11217727	行程开关	Y	1	
7	11211615	六角螺钉	Y	2	
8	14400483	小时表	Y	1	
9	11215624	支架	Y	1	
10	14401470	罩盖	Y	1	
11	14401709	翘板开关	Y	1	
12	11210756	翘板开关总成	Y	1	
13	14401422	罩盖	Y	1	
14	11211314	罩盖	Y	1	
15	11210042	法兰螺钉	Y	2	
16	11211608	螺栓	Y	3	
17	11210089	六角螺钉	Y	4	
18	11210024	垫圈	Y	3	
19	11219655	开关盒	Y	1	
20	11210323	翘板开关总成	Y	1	
21	14400104	纽扣开关总成	Y	1	
22	11220167	开关	Y	1	

基本控制单元 Basic control




P4110-58-3670-004

洗涤器 Water jet unit




P4300-58-3634-001

内部电子系统 Control unit




P4300-58-3640-005

V-ECU V-ecu install



P4300-58-3660-001

远程信息处理 Telematics control unit




P4300-58-3660-009

序号 Key	零件代号 Part No.		名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14404201	固定板	Plate	Y	1	
2	14404200	GPS终端	Control unit	Y	1	
3	11210057	垫圈	Washer	Y	2	
4	11219877	螺栓	Screw	Y	2	
5	11210042	法兰螺钉	Flange screw	Y	2	
6	11212854	GPS密码键盘	Keyboard	Y	1	


SDLG

键区 Keyboard




P4300-58-3670-008.21974

仪表盘电缆线束 Cable harness




P4300-58-3710-017

保险丝和继电器中央接线盒 Fuse and relay unit



P4300-58-3723-003.20401


保险丝和继电器中央接线盒 Fuse and relay unit



P4300-14408224



序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14401617	电器盒螺栓	Y	4	
2	11213706	O型圈	Y	4	
3	14401615	电器盒盖	Y	1	
4	11218714	环..	Y	4	
5	11219423	密封条	Y	1	
6	14408225	EDB标识	Y	1	
7	11218674	二极管	Y	5	
8	11215627	继电器	Y	4	
9	11220527	继电器	Y	2	
10	11214265	保险丝	Y	3	
11	11214266	保险丝	Y	21	
12	11211867	保险丝	Y	10	
13	11210087	六角螺钉	Y	6	
14	11220892	印刷板	Y	1	
15	11219426	电缆套筒	Y	4	
16	11219427	套管	Y	4	
17	14401616	电器盒	Y	1	
18	11218713	塞	Y	1	
19	11219429	电缆套筒	Y	1	
20	11220891	保险盒夹	Y	1	
21	11210024	垫圈	Y	2	
22	11210061	弹簧垫圈	Y	2	
23	11210085	六角螺钉	Y	2	

显示器 Display panel





P4300-58-3810-002

收音机 Radio cassette



P4300-58-3932-002



发动机线束总成 Engine cable install



P4400-58-3710-008


序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	14401834	EMS线束	Y	1	
2	14401718	发动机线束	Y	1	
3	11214602	起动机至发电机线束	Y	1	
4	11210840	线束	Y	1	
5	14407073	支架	Y	1	
6	11211053	锁紧螺母	Y	2	
7	14400342	扎带	Y	7	
8	14400341	扎带	Y	8	
9	14400340	扎带座	Y	6	
10	14400370	扎带	Y	1	
11	14402824	支架	Y	1	
12	11210537	接插件固定夹	Y	2	
13	14402823	支架	Y	1	
14	11210219	螺母	Y	1	
15	11210189	六角螺钉	Y	2	
16	11210057	垫圈	Y	1	
17	11210062	弹簧垫圈	Y	1	
18	11214768	垫圈	Y	1	
19	11210059	垫圈	Y	2	
20	11214757	法兰螺钉	Y	1	
21	11214756	法兰螺钉	Y	2	
22	11210033	法兰螺钉	Y	3	
23	11210032	法兰螺钉	Y	3	
24	11210025	锯齿垫圈	Y	1	
25	14402822	支架	Y	1	
26	11214599	接插件固定夹	Y	1	
27	11220169	六角螺丝M8*16	Y	1	
28	11220174	线束	Y	1	
29	11219591	橡胶套	Y	1	
30	11214766	管夹	Y	2	

发动机线束总成 Engine cable install



P4400-58-3710-008

预热器总成 Preheater relay




P4400-58-3723-012

序号 Key	零件代号 Part No.	名称 Description	是否配件 Spare parts Y/N	数量 Qty	备注 Remarks
1	11221057	电缆	Y	1	
2	11220529	板	N	1	
3	14405031	预热继电器支架	Y	1	
4	11220530	护套	Y	1	
5	11220531	护套	Y	2	
6	11220532	螺母	Y	1	
7	11220533	保险丝	Y	1	
8	11221058	电缆	Y	1	
9	11211143	预热继电器	Y	1	
10	11210024	垫圈	Y	2	
11	11220535	线束	Y	1	
12	11210084	六角螺钉	Y	2	
13	14405879	预热继电器总成	Y	1	
14	11210033	法兰螺钉	Y	2	

SDLG

控制单元装置 Control unit



P4400-58-8730-001

